




AMA Analytical Services, Inc.  
Focused On Results.



**NY ELAP**

Lab ID 10920



## **Analytical Report for:**

# **Testing of Official Samples of Talc Containing Cosmetics for Asbestiform Fibers**

**Contract Number: 75F40122P000335**

**Assignment DFIG# 23-19, Batch No. 04032023 (Batch #1)  
AMA COC No. 646090**

**US FDA  
Office of Cosmetics & Colors  
4300 River Road  
College Park, MD 20740**



AMA Analytical Services, Inc.  
**Focused On Results. CERTIFICATE OF ANALYSIS**

Chain of Custody: 646090  
 Client: US Food & Drug Administration  
 Address: Office of Cosmetics & Colors  
 4300 River Road  
 College Park, MD 20740  
 Attention: John Gasper

Job Name: Assignment DFPG #23-19  
 Job Location: Batch 1 (No. 04032023)  
 Job Number: CLIN 0001  
 PO Number: 75F40122P000335

Date Submitted: 4/13/2023  
 Date Analyzed: 5/30/2023 - 6/22/2023  
 Report Date: 8/22/2023  
 Date Sampled: Not Provided  
 Person Submitting: Sabrina McKinney  
 Revised:

**SUMMARY OF ANALYSIS**

| AMA Sample ID | Client Sample ID | TEM LOD                           | TEM LOQ                           | % Chrysotile by TEM               | % Tremolite by TEM                | % Total Chrysotile & Tremolite by TEM | % Asbestos by PLM | % Organics | % Acid Soluble | % Other | Comments |
|---------------|------------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|---------------------------------------|-------------------|------------|----------------|---------|----------|
|               |                  | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation     |                   |            |                |         |          |
| 646090-1A     | 04032023-1       | 0.00000313%                       | 0.00001253%                       | ND                                | ND                                | < 0.00001%                            | ND                | 23.45%     | 22.58%         | 53.97%  |          |
| 646090-1B     | 04032023-1       | 0.00000363%                       | 0.00001450%                       | ND                                | ND                                | < 0.00001%                            | ND                | 23.38%     | 21.86%         | 54.77%  |          |
| 646090-1C     | 04032023-1       | 0.00000517%                       | 0.00002070%                       | ND                                | ND                                | < 0.00002%                            | ND                | 23.37%     | 24.54%         | 52.09%  |          |
| 646090-2A     | 04032023-2       | 0.00000506%                       | 0.00002022%                       | ND                                | ND                                | < 0.00002%                            | ND                | 21.53%     | 6.70%          | 71.77%  |          |
| 646090-2B     | 04032023-2       | 0.00000518%                       | 0.00002074%                       | ND                                | ND                                | < 0.00002%                            | ND                | 21.52%     | 9.64%          | 68.84%  |          |
| 646090-2C     | 04032023-2       | 0.00000368%                       | 0.00001471%                       | ND                                | ND                                | < 0.00001%                            | ND                | 21.58%     | 8.24%          | 70.18%  |          |
| 646090-3A     | 04032023-3       | 0.00000351%                       | 0.00001406%                       | ND                                | ND                                | < 0.00001%                            | ND                | 9.18%      | 10.71%         | 80.11%  |          |
| 646090-3B     | 04032023-3       | 0.00000549%                       | 0.00002197%                       | ND                                | ND                                | < 0.00002%                            | ND                | 9.16%      | 11.18%         | 79.66%  |          |
| 646090-3C     | 04032023-3       | 0.00000380%                       | 0.00001521%                       | ND                                | ND                                | < 0.00002%                            | ND                | 9.28%      | 9.62%          | 81.11%  |          |
| 646090-4A     | 04032023-4       | 0.00000414%                       | 0.00001657%                       | ND                                | ND                                | < 0.00002%                            | ND                | 12.77%     | 8.70%          | 78.54%  |          |
| 646090-4B     | 04032023-4       | 0.00000410%                       | 0.00001639%                       | ND                                | ND                                | < 0.00002%                            | ND                | 12.86%     | 9.42%          | 77.72%  |          |
| 646090-4C     | 04032023-4       | 0.00000374%                       | 0.00001497%                       | ND                                | ND                                | < 0.00001%                            | ND                | 12.45%     | 9.81%          | 77.74%  |          |
| 646090-5A     | 04032023-5       | 0.00000563%                       | 0.00002253%                       | ND                                | ND                                | < 0.00002%                            | ND                | 0.18%      | 11.05%         | 88.77%  |          |
| 646090-5B     | 04032023-5       | 0.00000471%                       | 0.00001883%                       | ND                                | ND                                | < 0.00002%                            | ND                | 0.18%      | 8.90%          | 90.92%  |          |
| 646090-5C     | 04032023-5       | 0.00000550%                       | 0.00002202%                       | ND                                | ND                                | < 0.00002%                            | ND                | 0.17%      | 9.14%          | 90.69%  |          |
| 646090-6A     | 04032023-6       | 0.00000504%                       | 0.00002015%                       | ND                                | ND                                | < 0.00002%                            | ND                | 26.94%     | 9.34%          | 63.73%  |          |
| 646090-6B     | 04032023-6       | 0.00000444%                       | 0.00001775%                       | ND                                | ND                                | < 0.00002%                            | ND                | 26.90%     | 8.14%          | 64.96%  |          |
| 646090-6C     | 04032023-6       | 0.00000343%                       | 0.00001370%                       | ND                                | ND                                | < 0.00001%                            | ND                | 26.94%     | 8.53%          | 64.52%  |          |
| 646090-7A     | 04032023-7       | 0.00000396%                       | 0.00001584%                       | ND                                | ND                                | < 0.00002%                            | ND                | 20.95%     | 10.66%         | 68.40%  |          |
| 646090-7B     | 04032023-7       | 0.00000463%                       | 0.00001851%                       | ND                                | ND                                | < 0.00002%                            | ND                | 20.96%     | 9.88%          | 69.15%  |          |
| 646090-7C     | 04032023-7       | 0.00000488%                       | 0.00001953%                       | ND                                | ND                                | < 0.00002%                            | ND                | 21.02%     | 9.71%          | 69.27%  |          |
| 646090-8A     | 04032023-8       | 0.00000509%                       | 0.01872612%                       | ND                                | < 0.01873%                        | < 0.01873%                            | ND                | 13.44%     | 11.40%         | 75.15%  |          |
| 646090-8B     | 04032023-8       | 0.00000586%                       | 0.00002343%                       | ND                                | ND                                | < 0.00002%                            | ND                | 13.45%     | 10.85%         | 75.70%  |          |
| 646090-8C     | 04032023-8       | 0.00000517%                       | 0.00347711%                       | ND                                | < 0.00348%                        | < 0.00348%                            | ND                | 13.48%     | 12.65%         | 73.86%  |          |
| 646090-9A     | 04032023-9       | 0.00000586%                       | 0.00002346%                       | ND                                | ND                                | < 0.00002%                            | ND                | 12.12%     | 18.48%         | 69.41%  |          |
| 646090-9B     | 04032023-9       | 0.00001237%                       | 0.00004950%                       | ND                                | ND                                | < 0.00005%                            | ND                | 12.07%     | 19.18%         | 68.75%  |          |
| 646090-9C     | 04032023-9       | 0.00000565%                       | 0.00002260%                       | ND                                | ND                                | < 0.00002%                            | ND                | 12.06%     | 18.68%         | 69.26%  |          |
| 646090-10A    | 04032023-10      | 0.00000785%                       | 0.00003139%                       | ND                                | ND                                | < 0.00003%                            | ND                | 4.43%      | 11.51%         | 84.06%  |          |
| 646090-10B    | 04032023-10      | 0.00000602%                       | 0.00002409%                       | ND                                | ND                                | < 0.00002%                            | ND                | 4.45%      | 11.76%         | 83.79%  |          |
| 646090-10C    | 04032023-10      | 0.00000706%                       | 0.00002826%                       | ND                                | ND                                | < 0.00003%                            | ND                | 4.49%      | 10.13%         | 85.38%  |          |
| 646090-11A    | 04032023-11      | 0.00000445%                       | 0.00001779%                       | ND                                | ND                                | < 0.00002%                            | ND                | 11.63%     | 5.68%          | 82.69%  |          |
| 646090-11B    | 04032023-11      | 0.00000390%                       | 0.00001558%                       | ND                                | ND                                | < 0.00002%                            | ND                | 11.65%     | 5.76%          | 82.59%  |          |
| 646090-11C    | 04032023-11      | 0.00000330%                       | 0.00001320%                       | ND                                | ND                                | < 0.00001%                            | ND                | 11.66%     | 5.83%          | 82.51%  |          |
| 646090-12A    | 04032023-12      | 0.00000505%                       | 0.00002018%                       | ND                                | ND                                | < 0.00002%                            | ND                | 17.48%     | 7.45%          | 75.07%  |          |
| 646090-12B    | 04032023-12      | 0.00000467%                       | 0.00001867%                       | ND                                | ND                                | < 0.00002%                            | ND                | 17.42%     | 6.39%          | 76.18%  |          |
| 646090-12C    | 04032023-12      | 0.00000541%                       | 0.00002162%                       | ND                                | ND                                | < 0.00002%                            | ND                | 17.43%     | 7.12%          | 75.44%  |          |
| 646090-13A    | 04032023-13      | 0.00000491%                       | 0.00001964%                       | ND                                | ND                                | < 0.00002%                            | ND                | 2.43%      | 2.79%          | 94.78%  |          |
| 646090-13B    | 04032023-13      | 0.00000496%                       | 0.00001984%                       | ND                                | ND                                | < 0.00002%                            | ND                | 2.37%      | 2.53%          | 95.10%  |          |
| 646090-13C    | 04032023-13      | 0.00000554%                       | 0.00002216%                       | ND                                | ND                                | < 0.00002%                            | ND                | 2.44%      | 2.76%          | 94.80%  |          |
| 646090-14     | 04032023-14.1    | 0.00000193%                       | 0.00000773%                       | ND                                | ND                                | < 0.00001%                            | ND                | 45.02%     | 3.82%          | 51.16%  |          |
| 646090-15     | 04032023-14.2    | 0.00000185%                       | 0.00000739%                       | ND                                | ND                                | < 0.00001%                            | ND                | 48.66%     | 3.73%          | 47.61%  |          |



# AMA Analytical Services, Inc.

Focused On Results. **CERTIFICATE OF ANALYSIS**

**Chain of Custody:** 646090  
**Client:** US Food & Drug Administration  
**Address:** Office of Cosmetics & Colors  
4300 River Road  
College Park, MD 20740  
**Attention:** John Gasper

**Job Name:** Assignment DFPG #23-19  
**Job Location:** Batch 1 (No. 04082023)  
**Job Number:** CLIN 0001  
**PO Number:** 75F40122P000335

**Date Submitted:** 4/13/2023  
**Date Analyzed:** 5/30/2023 - 6/22/2023  
**Report Date:** 8/22/2023  
**Date Sampled:** Not Provided  
**Person Submitting:** Sabrina McKinney  
**Revised:**

### SUMMARY OF ANALYSIS

| AMA Sample ID | Client Sample ID | TEM LOD                           | TEM LOQ                           | % Chrysotile by TEM               | % Tremolite by TEM                | % Total Chrysotile & Tremolite by TEM | % Asbestos by PLM | % Organics | % Acid Soluble | % Other | Comments |
|---------------|------------------|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|---------------------------------------|-------------------|------------|----------------|---------|----------|
|               |                  | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation | Using ASTM D5756 Mass Calculation     |                   |            |                |         |          |
| 646090-16     | 04032023-14.3    | 0.00000168%                       | 0.00000673%                       | ND                                | ND                                | < 0.00001%                            | ND                | 48.76%     | 3.87%          | 47.38%  |          |

**LOD** = Limit of Detection      **LOQ** = Limit of Quantification      **ND** = Not Detected      **PLM** = Polarized Light Microscopy      **TEM** = Transmission Electron Microscopy

**Analytical Method(s):** PLM by Modified NY ELAP 198.6  
TEM by Modified NY ELAP 198.4/ASTM D5756

**Analyst(s):** PLM  
TEM

(b) (6)

Andreas Saldivar

**Technical Director:** Andreas Saldivar

All results are to be considered preliminary and subject to change unless signed by the Technical Director or Deputy

This report applies only to the sample, or samples, investigated and is not necessarily indicative of the quality or condition of apparently identical or similar products. As a mutual protection to clients, the public, and these Laboratories, this report is submitted and accepted for the exclusive use of the client to whom it is addressed and upon the condition that it is not to be used, in whole or in part, in any advertising or publicity matter nor shall it be reproduced, except in full, without prior written authorization from us. Sample types, locations, collection protocols, air volumes and/or surface wipe area measurement are based upon information provided by the person(s) submitting them, and unless collected by personnel of these Laboratories, we expressly disclaim any knowledge and liability for the accuracy and completeness of this information and for analytical results calculated based on this information. Residual sample material will be discarded in accordance with the appropriate regulatory guidelines, unless otherwise requested by the client. NVLAP accreditation applies only to polarized light microscopy of bulk samples and transmission electron microscopy of AHERA air samples. This report must not be used to claim, and does not imply product certification, approval, or endorsement by NY ELAP, AIHA, NVLAP, NIST, or any agency of the Federal Government. All rights reserved. AMA Analytical Services, Inc.

# FDA Office of Cosmetics & Colors

## Table of Contents

### COC 646090

|  |     |
|--|-----|
| Record Changes Report.....                                 | 5   |
| Chain of Custody .....                                     | 6   |
| UPS Delivery Confirmation.....                             | 11  |
| Case Narrative.....  | 15  |
| Sample Receipt Description.....                            | 17  |
| 646090-1A, 1B, 1C/04032023-1.....                          | 19  |
| 646090-2A, 2B, 2C/04032023-2.....                          | 20  |
| 646090-3A, 3B, 3C/02212022-3.....                          | 21  |
| 646090-4A, 4B, 4C/02212022-4.....                          | 22  |
| 646090-5A, 5B, 5C/04032023-5.....                          | 23  |
| 646090-6A, 6B, 6C/04032023-6.....                          | 24  |
| 646090-7A, 7B, 7C/04032023-7.....                          | 25  |
| 646090-8A, 8B, 8C/04032023-8.....                          | 26  |
| 646090-9A, 9B, 9C/04032023-9.....                          | 27  |
| 646090-10A, 10B, 10C/04032023-10.....                      | 28  |
| 646090-11A, 11B, 11C/04032023-11.....                      | 29  |
| 646090-12A, 12B, 12C/04032023-12.....                      | 30  |
| 646090-13A, 13B, 13C/04032023-13.....                      | 31  |
| 646090-14, 15, 16/04032023-14.1, 14.2, 14.3 .....          | 32  |
| Sample Preparation .....                                   | 33  |
| PLM Analysis.....  | 34  |
| TEM Analysis.....  | 34  |
| Calculations .....   | 35  |
| Limits of Detection and Quantification .....               | 35  |
| Discussion and Interpretation of Analytical Findings ..... | 36  |
| 646090-1A, 1B, 1C/Client Sample: 04032023-1 .....          | 36  |
| 646090-2A, 2B, 2C/Client Sample: 04032023-2 .....          | 52  |
| 646090-3A, 3B, 3C/Client Sample: 04032023-3 .....          | 67  |
| 646090-4A, 4B, 4C/Client Sample: 04032023-4 .....          | 77  |
| 646090-5A, 5B, 5C/Client Sample: 04032023-5 .....          | 97  |
| 646090-6A, 6B, 6C/Client Sample: 04032023-6 .....          | 108 |
| 646090-7A, 7B, 7C/Client Sample: 04032023-7 .....          | 121 |
| 646090-8A, 8B, 8C/Client Sample: 04032023-8 .....          | 132 |
| 646090-9A, 9B, 9C/Client Sample: 04032023-9 .....          | 148 |
| 646090-10A, 10B, 10C/Client Sample: 04032023-10 .....      | 157 |
| 646090-11A, 11B, 11C/Client Sample: 04032023-11 .....      | 167 |
| 646090-12A, 12B, 12C/Client Sample: 04032023-12 .....      | 177 |
| 646090-13A, 13B, 13C/04032023-13.....                      | 187 |
| 646090-14, 15, 16/04032023-14.1, 14.2, 14.3 .....          | 192 |

**Asbestos · Lead · Mold · Nano**

|   |     |
|---|-----|
| QC Discussion .....                                       | 202 |
| Supporting Bench Sheets .....                             | 204 |
| Login Sheet .....   | 204 |
| Analytical Balance Verification Log.....                  | 205 |
| Daily PLM Scope Verification Log .....                    | 207 |
| Refractive Index Oil Verification Log .....               | 209 |
| Daily TEM Scope Verification Log(s) .....                 | 210 |
| QC Results Summary .....                                  | 217 |
| NB (Matrix) Blank Preparation Log.....                    | 218 |
| NB (Matrix) Blank Analytical Bench Sheet(s).....          | 220 |
| RB (Reference Sample) Analytical Bench Sheet(s) .....     | 222 |
| EB (TEM Grid) Blank Preparation Log .....                 | 223 |
| EB (TEM Grid) Blank Analytical Bench Sheet(s) .....       | 229 |
| Filtration Blank Analytical Bench Sheet(s).....           | 231 |
| Duplicate & Replicate QC Charts .....                     | 232 |
| PLM Gravimetric Reduction Bench Sheet(s).....             | 237 |
| TEM Gravimetric Reduction/Filtration Bench Sheet(s) ..... | 244 |
| Analytical Bench Sheets.....                              | 248 |
| 646090-1A, 1B, 1C/04032023-1.....                         | 248 |
| 646090-2A, 2B, 2C/04032023-2.....                         | 254 |
| 646090-3A, 3B, 3C/04032023-3.....                         | 260 |
| 646090-4A, 4B, 4C/04032023-4.....                         | 266 |
| 646090-5A, 5B, 5C/04032023-5.....                         | 272 |
| 646090-6A, 6B, 6C/04032023-6.....                         | 278 |
| 646090-7A, 7B, 7C/04032023-7.....                         | 284 |
| 646090-8A, 8B, 8C/04032023-8.....                         | 290 |
| 646090-9A, 9B, 9C/04032023-9.....                         | 296 |
| 646090-10A, 10B, 10C/04032023-10.....                     | 302 |
| 646090-11A, 11B, 11C/04032023-11.....                     | 308 |
| 646090-12A, 12B, 12C/04032023-12.....                     | 314 |
| 646090-13A, 13B, 13C/04032023-13.....                     | 320 |
| 646090-14, 15, 16/04032023-14.1, 14.2, 14.3 .....         | 326 |
| Duplicate QC Analytical Bench Sheets.....                 | 332 |
| 646090-17DQC (646090-14A/04032023-14.3).....              | 332 |
| Replicate QC Analytical Bench Sheet(s).....               | 334 |
| 646090-18RQC (646090-1A/04032023-1) .....                 | 334 |
| 646090-19RQC (646090-12A/04032023-12) .....               | 336 |

## Record Changes Report

| Date      | Description  |
|-----------|--|
| 8/25/2023 | P. 77: The word "Csection" was corrected to read "Calculations section" in the PLM analytical findings paragraph for sample 646090-4/04032023-4. |

**Chain of Custody**

**AMA Analytical Services, Inc.**  
*Focused On Results.*  
 AIHA-LAP (#100470) NVLAP (#101143-0) NY ELAP (#10920)  
 4475 Forbes Blvd. • Lanham, MD 20706  
 (301) 459-2640 • (800) 346-0961 • Fax (301) 459-2643  
[www.amalab.com](http://www.amalab.com)

(COC # Assigned upon arrival at lab.)

**646090**

**CHAIN OF CUSTODY**  
**Asbestos in Talc/Cosmetics**

**Mailing/Billing Information:**

Client Name: US Food & Drug Administration  
 Address: Office of Cosmetics and Colors  
 Address: 4300 River Road  
 Address: College Park, MD 20740  
 Phone #: \_\_\_\_\_ Fax #: \_\_\_\_\_

**Submittal Information:**

Job Name: Assignment DFIG #23-19  
 Job Location: Batch 1 (No. 04032023)  
 Job #: CLIN 1001 P.O. #: 75F40122P000335  
 Point of Contact: John Gasper Cell #: 240-402-1133  
 Collected by: \_\_\_\_\_ Cell #: \_\_\_\_\_

Reporting Info (Results provided as soon as technically feasible). If no TAT/Reporting Info is provided, AMA will assign defaults of 6-Weeks & email/fax to contacts of file.

| TURN AROUND TIME (TAT):   |  | REPORT TO:   |
|---|--|--|
| After Hours (must be pre-scheduled)   | Normal Business Hours  | <input checked="" type="checkbox"/> Email: <u>john.gasper@fda.hhs.gov</u>                          |
| After Hours Service is not provided for Asbestos in Talc/Cosmetics Analysis   | <input type="checkbox"/> 10-Day (2-Weeks)<br><input type="checkbox"/> 3-4 Weeks <input type="checkbox"/> 6- Weeks    Due Date: <u>5/31/2023</u><br><input checked="" type="checkbox"/> 4-6 Weeks | <input checked="" type="checkbox"/> Email CC 1: <u>steven.wolfgang.fda.hhs.gov</u>                 |
|   |  | <input type="checkbox"/> Email CC 2: _____   |
|   |  | <input type="checkbox"/> Verbals   |
| <b>Sample Type</b>  |  |  |
| <input checked="" type="checkbox"/> FDA Modified Procedures for PLM-ELAP 198.6 & TEM ELAP 198.4 (QTY)   |  |  |
| Data Package Level [Select One]: _____ Standard (Certificate of Analysis & Signed COC) _____ Level I (Standard + QA/QC Summary) _____ Level II (I + Bench Sheets) <input checked="" type="checkbox"/> Level III (II + Case Narrative) |  |  |
| *If field data sheets are submitted, there is no need to complete bottom section  |  | <input checked="" type="checkbox"/> All samples received in good condition unless otherwise noted. |

| Sample Information  |                                      |   |                       |
|---------------------|--------------------------------------|---|-----------------------|
| Sample Number       | No. of Aliquots to Prepare & Analyze | Sample Description (ie, color, container size, etc.)<br><small>[samples must be submitted blind such that AMA cannot determine the source of the material being submitted for analysis]</small>   | Comments/Instructions |
| Item #s 1 thru 14.4 | 3                                    | 13 '1-oz glass jars submitted in pink vacuum sealed plastic bags and 4 (4/sample) 50mL plastic centrifuge tubes in pink vacuum sealed plastic bags with custody seals intact (sealed by Sabrina McKinney & Andrea Heise 4/3/2023-4/11/2023) |                       |
|                     |                                      | See attached FDA COC for additional details.  |                       |
|                     |                                      |   |                       |
|                     |                                      |   |                       |
|                     |                                      |   |                       |
|                     |                                      |   |                       |
|                     |                                      |   |                       |
|                     |                                      |   |                       |

|                  |            |           |           |       |   |
|------------------|------------|-----------|-----------|-------|---|
| Relinquished by: | Print Name | Sign Name | Date      | Time  | Shipping Information<br><input checked="" type="checkbox"/> UPS<br><input type="checkbox"/> FedEx<br><input type="checkbox"/> USPS<br><input type="checkbox"/> In-Person<br><input type="checkbox"/> Drop Box<br><input type="checkbox"/> Other |
| Received by:     | (b) (6)    | (b) (6)   | 4/13/2023 | 09:35 |   |

**Asbestos • Lead • Mold • Nano**



1DFC 6th Ave & Kipling St  
Bldg 20, Door W-10  
P.O. Box 25087  
Denver, CO 80225-0087

April 12, 2023

AMA Analytical Services, Inc.  
Attn: (b) (6)  
4475 Forbes Blvd.  
Lanham, MD 20706  
Phone: 301-459-2640

Re: Samples for Asbestos Analysis, Batch #04032023

Dear (b) (6) :

Enclosed in the box are thirteen vials of approx. 5-g solid product and four tubes (from one sample) of approx. 30 mL of liquid product of commercial talc-containing cosmetic products being submitted for analysis for asbestiform fibers by transmission electron microscope (TEM) per FDA Assignment DFIG #23-19, Contract No. #75F40122P00335. Also included in box is one chain of custody form to be completed by recipient for tracking of sample batch at AMA. Please analyze samples as agreed.

The fourteen samples in this shipment constitute Batch 1 (No. 04032023) of the 50 samples that will be submitted to AMA for analysis in 2023.

If there are any questions, please contact: John Gasper: 240-402-1133 [john.gasper@fda.hhs.gov](mailto:john.gasper@fda.hhs.gov)

Best regards,

**Sabrina M. McKinney**  
Chemist

Chemistry Branch  
Denver Laboratory  
Office of Regulatory Affairs  
U.S. Food and Drug Administration  
T: 303-236-9665  
[sabrina.mckinney@fda.hhs.gov](mailto:sabrina.mckinney@fda.hhs.gov)

Enclosure: Chain of custody

**Asbestos · Lead · Mold · Nano**

|   |   |   |
|---|---|---|
| <b>FOOD AND DRUG ADMINISTRATION<br/>OFFICE OF REGULATORY AFFAIRS<br/>Office of Regulatory Science</b> | <b>Document Number:<br/>FORM-000796</b> | <b>Revision #: 00<br/>Revised:<br/>02/21/2020</b> |
| <b>Title:<br/>Cosmetic Talc Sample Chain-of-Custody Form</b>  |   | Page 1 of 3                                       |

Batch No: 04032023  
 Submitter: Sabrina M McKinney / Andrea S Heise  
 Assignment No./ Contract No.: DFPG# 23-19 / #75F40122P00335  
 AMA COC No.: \_\_\_\_\_  
 Date Sealed: 4/12/23 Sample Type: Official Samples

| Description of Evidence |          |   |
|-------------------------|----------|---|
| Item #                  | Quantity | Description of Item (Lab#, Lot #, Condition)            |
| 04032023-1              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-2              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-3              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-4              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-5              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-6              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-7              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-8              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-9              | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-10             | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-11             | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-12             | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-13             | 1 vial   | Approx. 5 g of prepared talc-containing cosmetic sample |
| 04032023-14.1 to 14.4   | 4 tubes  | 4 tubes of ~30 mL each of liquid product                |


Adapted from: Technical Working Group on Biological Evidence Preservation. *The Biological Evidence Preservation Handbook: Best Practices for Evidence Handlers*. U.S. Department of Commerce, National Institute of Standards and Technology. 2013.

For the most current and official copy, check QMiS

**Asbestos · Lead · Mold · Nano**



|   |  |  |
|---|--|--|
| <b>FOOD AND DRUG ADMINISTRATION</b><br><b>OFFICE OF REGULATORY AFFAIRS</b><br><b>Office of Regulatory Science</b> | <b>Document Number:</b><br>FORM-000796 | <b>Revision #: 00</b><br><b>Revised:</b><br>02/21/2020 |
| Title:<br><b>Cosmetic Talc Sample Chain-of-Custody Form</b>   |  | Page 2 of 3  |

| Chain of Custody         |         |                             |  |                   |
|--------------------------|---------|-----------------------------|--|-------------------|
| Item #                   | Date    | Released by<br>(Print Name) | Released by<br>(Signature)   | Comments/Location |
| 0403202<br>3-1 –<br>14.4 | 4/12/23 | Sabrina McKinney            |  | ORA DENL HAF      |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |

| Chain of Custody |               |                             |                            |                   |
|------------------|---------------|-----------------------------|----------------------------|-------------------|
| Item #           | Date/Time     | Received by<br>(Print Name) | Received by<br>(Signature) | Comments/Location |
| 1-14.4           | 4/12/23 09:55 | (b) (6)                     | (b) (6)                    | AMA               |
|                  |               |                             |                            |                   |
|                  |               |                             |                            |                   |
|                  |               |                             |                            |                   |
|                  |               |                             |                            |                   |
|                  |               |                             |                            |                   |
|                  |               |                             |                            |                   |
|                  |               |                             |                            |                   |


| Final Disposal Authority<br>Authorization for Disposal  |
|---|
| Item(s) #: _____ on this document is/are no longer needed as evidence and is/are authorized for disposal by (check appropriate disposal method)<br><input type="checkbox"/> Return to Submitter <input type="checkbox"/> Destruction<br>Name of Authorizing Official: _____ Date: _____<br><br>Signature: _____ |


Adapted from: Technical Working Group on Biological Evidence Preservation. *The Biological Evidence Preservation Handbook: Best Practices for Evidence Handlers*. U.S. Department of Commerce, National Institute of Standards and Technology. 2013.

For the most current and official copy, check QMiS

**Asbestos • Lead • Mold • Nano**

|   |  |  |
|---|--|--|
| <b>FOOD AND DRUG ADMINISTRATION</b><br><b>OFFICE OF REGULATORY AFFAIRS</b><br><b>Office of Regulatory Science</b> | <b>Document Number:</b><br>FORM-000796 | <b>Revision #: 00</b><br><b>Revised:</b><br>02/21/2020 |
| Title:<br><b>Cosmetic Talc Sample Chain-of-Custody Form</b>   |  | Page 2 of 3  |

| Chain of Custody         |         |                             |  |                   |
|--------------------------|---------|-----------------------------|--|-------------------|
| Item #                   | Date    | Released by<br>(Print Name) | Released by<br>(Signature)   | Comments/Location |
| 0403202<br>3-1 –<br>14.4 | 4/12/23 | Sabrina McKinney            |  | ORA DENL HAF      |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |
|                          |         |                             |  |                   |

| Chain of Custody |               |                             |  |                   |
|------------------|---------------|-----------------------------|--|-------------------|
| Item #           | Date/Time     | Received by<br>(Print Name) | Received by<br>(Signature)   | Comments/Location |
| 1-14.4           | 4/12/23 09:55 | (b) (6)                     |  | AMA               |
|                  |               |                             |  |                   |
|                  |               |                             |  |                   |
|                  |               |                             |  |                   |
|                  |               |                             |  |                   |
|                  |               |                             |  |                   |
|                  |               |                             |  |                   |
|                  |               |                             |  |                   |

| Final Disposal Authority<br>Authorization for Disposal  |
|---|
| Item(s) #: _____ on this document is/are no longer needed as evidence and is/are authorized for disposal by (check appropriate disposal method)<br><input type="checkbox"/> Return to Submitter <input type="checkbox"/> Destruction<br>Name of Authorizing Official: _____ Date: _____<br><br>Signature: _____ |

Adapted from: Technical Working Group on Biological Evidence Preservation. *The Biological Evidence Preservation Handbook: Best Practices for Evidence Handlers*. U.S. Department of Commerce, National Institute of Standards and Technology. 2013.

For the most current and official copy, check QMiS

**Asbestos • Lead • Mold • Nano**

## UPS Delivery Confirmation

# Proof of Delivery

Dear Customer,

This notice serves as proof of delivery for the shipment listed below.

**Tracking Number**

(b) (6)

**Weight**

1.00 LBS

**Service**

UPS Next Day Air®

**Shipped / Billed On**

04/09/2021

**Delivered On**

04/12/2021 9:41 A.M.

**Delivered To**

LANHAM, MD, US

**Received By**

(b) (6)

**Left At**

Reception

Thank you for giving us this opportunity to serve you. Details are only available for shipments delivered within the last 120 days. Please print for your records if you require this information after 120 days.

Sincerely,

UPS

Tracking results provided by UPS: 04/12/2021 6:06 P.M. EST

**Asbestos · Lead · Mold · Nano**

**Dana Hudson Nicodemus**

**From:** UPS <pkginfo@ups.com >  
**Sent:** Monday, April 12, 2021 6:08 PM  
**To:** (b) (6)  
**Subject:** UPS Status Notification, Tracking Number (b) (6)



Please see below for package information and current transit status.  
Scheduled Delivery Date: Monday, 04/12/2021



**Shipment Details**

**Tracking Detail**

Your package is on time with a scheduled delivery date of 04/12/2021

**Tracking Number:** (b) (6)  
**Status:** Delivered  
**Scheduled Delivery:** 04/12/2021  
**Shipped To:** LANHAM, MD, US  
**UPS Service:** UPS Next Day Air®  
**Number of Packages:** 1  
**Weight:** 1.0 LBS

**Package Progress**

| Location       | Date       | Local Time | Description |
|----------------|------------|------------|-------------|
| LANHAM, MD, US | 04/12/2021 | 09:41 AM   | DELIVERED   |

|  |            |          |  |
|--|------------|----------|--|
| Landover, MD, United States  | 04/12/2021 | 09:17 AM | Out For Delivery Today   |
| Landover, MD, United States  | 04/12/2021 | 04:56 AM | Loaded on Delivery Vehicle                                     |
| Landover, MD, United States  | 04/12/2021 | 04:03 AM | Processing at UPS Facility                                     |
| Landover, MD, United States  | 04/11/2021 | 11:45 PM | Arrived at Facility  |
| Laurel, MD, United States  | 04/11/2021 | 11:16 PM | Departed from Facility   |
| Laurel, MD, United States  | 04/11/2021 | 02:22 PM | Processing at UPS Facility                                     |
| Laurel, MD, United States  | 04/11/2021 | 11:49 AM | Arrived at Facility  |
| Rockford, IL, United States  | 04/10/2021 | 09:40 PM | Departed from Facility   |
| Rockford, IL, United States  | 04/10/2021 | 04:40 PM | Arrived at Facility  |
| Denver, CO, United States  | 04/09/2021 | 10:24 PM | Departed from Facility   |
| Denver, CO, United States  | 04/09/2021 | 09:09 PM | Arrived at Facility  |
| Commerce City, CO, United States                                   | 04/09/2021 | 08:35 PM | Departed from Facility   |
| Commerce City, CO, United States                                   | 04/09/2021 | 05:32 PM | Origin Scan  |
| Commerce City, CO, United States                                   | 04/09/2021 | 03:52 PM | Pickup Scan  |
| United States  | 04/09/2021 | 02:56 PM | Shipper created a label, UPS has not received the package yet. |
| Tracking results provided by UPS 04/12/2021 6:08 P.M. Eastern Time |            |          |  |

**NOTICE:** UPS authorizes you to use UPS tracking systems solely to track shipments tendered by or for you to UPS for delivery and for no other purpose. Any other use of UPS tracking systems and information is strictly prohibited.



[Download the UPS mobile app](#)

© 2021 United Parcel Service of America, Inc. UPS, the UPS brandmark, and the color brown are trademarks of United Parcel Service of America, Inc. All rights reserved.

All trademarks, trade names, or service marks that appear in connection with UPS's services are the property of their respective owners.

Please do not reply directly to this email. UPS will not receive any reply message.

[Review the UPS Privacy Notice](#)

[For Questions, Visit Our Help and Support Center](#)

## Case Narrative

**Client Name:** FDA Office of Cosmetics & Colors      **Contact:** John Gasper  
**Contract Number:** 75F40122P000335      **Phone:** (240) 402-1133  
**Job Name/Location:** Assignment DFIG# 23-19      **Email:** [john.gasper@fda.hhs.gov](mailto:john.gasper@fda.hhs.gov)  
Batch No. 04032023 (Batch #1)  
**AMA COC Number:** 646090      **Date Received:** April 13, 2023

| AMA Sample No. | Client Sample No. | Sample Description  | Analytical Method                  |
|----------------|-------------------|---|------------------------------------|
| 646090-1A      | 04032023-1        | Dark brown colored, slightly clumpy powder with a matte appearance      | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-1B      | 04032023-1        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-1C      | 04032023-1        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-2A      | 04032023-2        | Black/brown colored, slightly clumpy powder with a matte appearance     | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-2B      | 04032023-2        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-2C      | 04032023-2        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-3A      | 04032023-3        | Very dark brown colored, slightly clumpy powder with a matte appearance | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-3B      | 04032023-3        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-3C      | 04032023-3        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-4A      | 04032023-4        | Brown colored, slightly clumpy powder with a matte appearance           | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-4B      | 04032023-4        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-4C      | 04032023-4        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-5A      | 04032023-5        | White colored, fine powder with a matte appearance                      | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-5B      | 04032023-5        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |

**Asbestos · Lead · Mold · Nano**

| AMA Sample No. | Client Sample No. | Sample Description  | Analytical Method                  |
|----------------|-------------------|---|------------------------------------|
| 646090-5C      | 04032023-5        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-6A      | 04032023-6        | Raspberry colored, slightly clumpy powder with a matte appearance                       | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-6B      | 04032023-6        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-6C      | 04032023-6        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-7A      | 04032023-7        | Tan colored (with cool gray undertones), slightly clumpy powder with a matte appearance | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-7B      | 04032023-7        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-7C      | 04032023-7        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-8A      | 04032023-8        | Nude colored, slightly clumpy powder with a slight pearlescent appearance               | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-8B      | 04032023-8        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-8C      | 04032023-8        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-9A      | 04032023-9        | Dark chocolate colored, slightly clumpy powder with a matte appearance                  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-9B      | 04032023-9        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-9C      | 04032023-9        |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-10A     | 04032023-10       | Nude colored, slightly clumpy powder with a matte appearance                            | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-10B     | 04032023-10       |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-10C     | 04032023-10       |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-11A     | 04032023-11       | White colored, fine powder with a matte appearance                                      | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-11B     | 04032023-11       |   | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |

**Asbestos · Lead · Mold · Nano**



| AMA Sample No. | Client Sample No. | Sample Description                                 | Analytical Method                  |
|----------------|-------------------|--|------------------------------------|
| 646090-11C     | 04032023-11       |  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-12A     | 04032023-12       | White colored, fine powder with a matte appearance | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-12B     | 04032023-12       |  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-12C     | 04032023-12       |  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-13A     | 04032023-13       | White colored, fine powder with a matte appearance | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-13B     | 04032023-13       |  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-13C     | 04032023-13       |  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-14      | 04032023-14.1     | Tan colored, opaque liquid                         | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-15      | 04032023-14.2     |  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |
| 646090-16      | 04032023-14.3     |  | Mod. PLM ELAP 198.6/TEM ELAP 198.4 |

Summary of Samples Received 1

**Requested Analyses: PLM Analysis for asbestos fibers conducted by Modified NY ELAP Method 198.6 and TEM Analysis for asbestos fibers conducted by Modified NY ELAP Method 198.4**

### Sample Receipt Description

The samples were received at AMA Analytical Services, Inc. on April 13, 2023, at 09:35 via UPS Tracking No. (b) (6) by (b) (6), who assigned them to Chain of Custody (COC) No. 646090. This COC number served as the internal laboratory job number for tracking purposes. The set consisted of thirteen (13) powder samples submitted in ~1-oz glass jars, and one (1) liquid sample submitted in four (4) 50mL centrifuge tubes per sample. Each jar of powder was sealed with parafilm and individually packaged in a pink vacuum and custody sealed plastic bag. Each centrifuge tube was sealed with parafilm and each group of four (4) centrifuge tubes was packaged in a pink vacuum and custody sealed plastic bag. Conditions were checked upon receipt and all sample containers and custody seals were intact. The samples were entered into the AMA laboratory database on May 5, 2023, at 13:56 by (b) (6) and (b) (6). The samples were logged in for analysis in triplicate and each sample aliquot was assigned a unique laboratory identification number as shown in the table above. After sample login, the set was transferred to AMA's lockbox for storage.







The following pictures document the condition of samples upon receipt at AMA:

**Asbestos · Lead · Mold · Nano**




**Asbestos · Lead · Mold · Nano**

646090-1A, 1B, 1C/04032023-1





**Asbestos · Lead · Mold · Nano**

646090-2A, 2B, 2C/04032023-2










**Asbestos • Lead • Mold • Nano**

646090-3A, 3B, 3C/02212022-3





**Asbestos · Lead · Mold · Nano**

646090-4A, 4B, 4C/02212022-4








**Asbestos · Lead · Mold · Nano**

646090-5A, 5B, 5C/04032023-5



Asbestos · Lead · Mold · Nano



646090-6A, 6B, 6C/04032023-6



**Asbestos · Lead · Mold · Nano**





646090-7A, 7B, 7C/04032023-7




**Asbestos · Lead · Mold · Nano**

646090-8A, 8B, 8C/04032023-8







**Asbestos · Lead · Mold · Nano**

646090-9A, 9B, 9C/04032023-9











**Asbestos · Lead · Mold · Nano**

646090-10A, 10B, 10C/04032023-10










**Asbestos · Lead · Mold · Nano**

646090-11A, 11B, 11C/04032023-11









**Asbestos · Lead · Mold · Nano**

646090-12A, 12B, 12C/04032023-12



**Asbestos · Lead · Mold · Nano**

646090-13A, 13B, 13C/04032023-13



Asbestos • Lead • Mold • Nano

646090-14, 15, 16/04032023-14.1, 14.2, 14.3



Asbestos • Lead • Mold • Nano



## Sample Preparation

Samples were gravimetrically reduced and filtered by (b) (6) on: May 10, 2023, through May 12, 2023, for 646090-1A through 646090-2C, 646090-18RQC, and NB23-285/286; May 19, 2023, through May 30, 2023, for 646090-3A through 646090-4C, and NB23-311/312; May 31, 2023, through June 2, 2023, for 646090-4C (TEM Re-Prep), 646090-5A through 646090-6C, and NB23-332/333; June 2, 2023, through June 8, 2023, for the 646090-7A through 646090-9C, and NB23-336/337; June 7, 2023, through June 13, 2023, for 646090-10A through 646090-12C, 646090-19RQC and NB23-341/342; June 15, 2023, through June 20, 2023, for 646090-13A through 646090-13C and NB23-353/354; and June 14, 2023, through June 20, 2023, for 646090-14 through 646090-16, 646090-17DQC and NB23-353/354.

PLM slide preparations were made by (b) (6) : May 12, 2023, for 646090-1A through 646090-2C, 646090-18RQC and NB23-286; May 16, 2023, for 646090-3A through 646090-4C and NB23-312; June 1, 2023, for 646090-5A through 646090-6C and NB23-333; June 7, 2023, for 646090-7A through 646090-9C and NB23-337; June 9, 2023, for 646090-10A through 646090-12C, 646090-19RQC, and NB23-342; June 16, 2023, for 646090-13A through 646090-13C, and June 16, 2023, for 646090-14 through 646090-16 and NB23-354.

TEM Grid preparations were made by: (b) (6) on May 17, 2023, for 646090-1A through 646090-2C, NB23-285, 646090-18RQC, and 646090-DI1 through 646090-DI2; Ashley Rose on May 31, 2023, for 646090-3A through 646090-4B, NB23-311, and 646090-DI3 through 646090-DI4; Ashley Rose on June 2, 2023, for 646090-4C, 646090-DI4C, NB23-333, 646090-5A through 646090-6C, NB23-332, and 646090-DI5 through 646090-DI6; (b) (6) on June 8, 2023, for 646090-7A through 646090-9C, NB23-336, 646090-DI7 through 646090-DI9; (b) (6) on June 14, 2023, for 646090-10A through 646090-12C, 646090-19RQC, NB23-341, and 646090-DI10 through 646090-DI12; and (b) (6) on June 20, 2023 for 646090-13A through 646090-16, 646090-17DQC, NB23-353, and 646090-DI14 through 646090-DI17.

Sample preparation for powder materials consisted of the following steps:

- 1) Label and weigh two 8mL glass vials for each sample in the set – one vial for the PLM preparation and one vial for the TEM preparation.
- 2) Weigh out 0.1 to 0.8-grams of material and place in the corresponding 8mL glass vial. Record weight.
- 3) Burn samples at 480° C for at least 12 hours.
- 4) Record Post-Ash weight.
- 5) Treat ashed sample with reagent grade hydrochloric acid.
- 6) Filter acid reduced material with a pre-weighed disposable filtration apparatus onto a 47mm 0.4µm PolyCarbonate filter.
- 7) Place disposable filtration apparatus with filter into drying oven for 3 hours and then record Post-Acid Reduced weight.
- 8) Make four PLM slide preparations from the PLM residue for each sample in 1.550 dispersion oil. Make additional preparations in 1.605, 1.625, 1.680 and 1.700 dispersion oil(s) as necessary for particle identification.
- 9) Weigh a portion of the material from the TEM residue and place it into the corresponding pre-weighed 100mL jar.
- 10) Fill the 100mL jar with deionized water.
- 11) Sonicate the jar for ~5-minutes.
- 12) Filter 0.1mL to 2mL of the solution onto a 47mm 0.22µm MCE filter.
- 13) Dry the filter for ~10-minutes then collapse, carbon coat, and place on a 3 TEM grids.

Sample preparation for liquid materials consisted of the following steps:

- 1) Add an aliquot of liquid to a pre-weighed crucible.
- 2) Record wet weight.
- 3) Place crucible into drying for 12-20 hours.
- 4) Record dry weight.

**Asbestos · Lead · Mold · Nano**

- 5) Follow steps 3 through 13 above.

TEM grid preparations were examined prior to analysis and were rejected if they met the following criteria:

- 1) Less than 50% of the carbon coating was intact
- 2) The grid was too dark due to incomplete dissolution of the filter
- 3) Heavy particulate loading in excess of 25%
- 4) Light particulate loading below 10%
- 5) Uneven distribution of particulate

#### Problems Encountered During Preparation & Resolutions:

On 5/25/2023, some of the post acid treatment residue was spilled for aliquot 646090-4C prior to being weighed. As a result, this aliquot was completely reprepared on May 31, 2023, through June 2, 2023, along with the other series of samples that were put through the muffle furnace on these dates (aliquots 646090-5A through 646090-6C). The matrix blank for this gravimetric reduction date range, NB23-332, was associated with the re-preparation for aliquot 646090-4C. A new filtration blank, 646090-DI4C, was also prepared.

No other problems were encountered during preparation. All gravimetric data was consistent among each group of aliquots and all TEM grid preparations were deemed acceptable for analysis.

#### **PLM Analysis**

Analysis was performed in accordance with NY ELAP 198.6 protocols. The analysis was conducted using an Olympus BH-2 polarized light microscope (PLM) equipped with a dispersion staining objective. All four slide preparations for each aliquot were examined; each slide preparation consisted of two (2) coverslips for a total of eight (8) coverslips. 400-point count was performed for those samples on which asbestos was observed. If no asbestos was detected on any of the slides, the percentage of fibrous components was determined by visual estimation. The results of this analysis are detailed below in the *Discussion and Interpretation of Analytical Findings* section for each individual sample.

#### Point Counting

If asbestos was observed on the slide preparations, the amount of asbestos was quantified using point count techniques. Point counting is a form of quantifying PLM samples. One of the oculars of each PLM microscope is etched with a crosshair. When point counting, whatever is under the crosshair is counted as one point of whatever the material is. Four (4) slide preparations with a total of eight (8) coverslips are prepared for each sample. The microscope mechanical stage is used to randomly move the slide. After each movement, whatever is under the crosshair, provided the point is not empty, is counted. Fifty (50) non-empty points are counted on each of the eight (8) coverslips for a total of four hundred (400) points. The total asbestos points counted are divided by the total points counted to calculate the percentage.

Example:

11 points of asbestos were counted out of the 400 total points

Slide percentage =  $(11\text{pts}/400\text{pts}) * 100\%$

Slide percentage = 2.75%

This number is not the final asbestos percentage. To calculate the final percentage, this number must be corrected to account for the material lost during gravimetric reduction preparation. See the *Calculations* section below for additional details.

#### **TEM Analysis**

Analysis was performed in accordance with modified NY ELAP Method 198.4 protocols. The analysis was performed using either a JEOL JEM-100CX II transmission electron microscope (TEM) equipped with ThermoFisher NSS System 7 Energy Dispersive X-Ray Analyzer (EDXA) or a JEOL 1400 Flash TEM equipped with ThermoFisher Pathfinder EDXA, at

**Asbestos · Lead · Mold · Nano**

magnifications of 19,000x or 20,000x. All TEM scopes are equipped with a Selective Area Electron Diffraction (SAED) setting that allows the operator to view the diffraction pattern of any mineral substance. Twenty (20) grid openings over two (2) grids were examined for each aliquot.

Modifications to the NY ELAP 198.4 Method were:

- 1) The residue was not placed in alcohol and prepared using the quick drop method. To obtain a more uniform preparation, the residue was placed in a jar and filled with 100mL of deionized water. The jar was sonicated, and a portion of the solution was filtered onto a 47mm 0.22µm MCE filter.
- 2) Any amphibole or chrysotile particle(s) observed were not quantified by visual estimation. The length and width of the observed particle(s) were measured, and the mass of each amphibole and chrysotile particle was calculated using the ASTM D5756 method.
- 3) All particles identified as amphibole were included with the counts/concentrations, regardless of size and aspect ratio.

The results of this analysis are detailed below in the *Discussion and Interpretation of Analytical Findings* section for each individual sample.

### Calculations

TEM ASTM D5756 Mass:

$$M = \pi/4 L * W^2 * D * 10^{-12}$$

Where: M: Mass  
L: Length  
W: Width  
D: Density

Gravimetric Reduction Percentages:

Organic:  $((W1 - W2) * 100/W1)$

Acid Soluble:  $((W2 - W3) * 100/W1)$

Other\* Percent:  $((W3/W1) * 100) - \text{Calculated Asbestos } \%$   
\*Other is defined as the non-asbestos, inorganic, acid insoluble portion of the sample

Where: W1: Weight of sample prior to ashing/acid wash  
W2: Weight of sample after ashing  
W3: Weight of sample after acid treatment

For liquid samples, the value for W1 is the dry weight mass.

Asbestos Percent Calculation:

TEM

$$\frac{EFA(\text{mm}^2) * 100\text{ml} * MA(\text{g}) * RW(\text{g})}{VF(\text{ml}) * IW(\text{g}) * AA(\text{mm}^2) * RJ(\text{g})}$$

(The calculated TEM value is then multiplied by 100 to convert it to percent)

Where: EFA: Effective filter area  
MA: Mass of asbestos  
RW: Weight of residue  
VF: Volume filtered  
IW: Initial weight of the sample  
AA: Area analyzed  
RJ: Weight of residue placed into the jar

PLM

$$(ASB * W3)/W1$$

Where: W1: Weight of sample prior to ashing/acid wash  
W3: Weight of sample after acid treatment  
ASB: Calculated Point Count Result

Note: All reported concentrations were calculated using the gravimetric data from the TEM preparations.

### Limits of Detection and Quantification

We used the mass of a 0.5 x 0.04-micron tremolite fiber as the basis for our calculations. Limit of detection (LOD) was defined as 1 fiber and limit of quantification (LOQ) was defined as 4 fibers.

Two aliquots of sample 04032023-8 contained very small amounts of tremolite that were below our four (4) fiber LOQ. For these samples, we defined our LOQ as follows:

646090-8A: mass of the single (1) observed tremolite particle plus the mass of three (3) tremolite fibers measuring 0.5 x 0.04 microns

646090-8C: mass of the two (2) observed tremolite particles plus the mass of two (2) tremolite fibers measuring 0.5 x 0.04 microns

### Discussion and Interpretation of Analytical Findings

646090-1A, 1B, 1C/Client Sample: 04032023-1

*PLM*  
All three aliquots of sample 04032023-1 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.


|           |                      |
|-----------|----------------------|
| 646090-1A | No Asbestos Detected |
| 646090-1B | No Asbestos Detected |
| 646090-1C | No Asbestos Detected |

*TEM*  
(b) (6) analyzed aliquot 1A on May 30, 2023, and aliquot 1C on May 31, 2023. (b) (6) analyzed aliquot 1b on May 30, 2023. The primary particle observed was mica; iron particles were also observed along with titanium particles, carbon particles, silicon particles, and very few talc particles. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-1A | No Asbestos Detected |
| 646090-1B | No Asbestos Detected |
| 646090-1C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

646090-1A, Mica Particle



646090 FDA\_002.jpg  
646090-1A  
Mica

2  $\mu\text{m}$   
HV=80kV  
Direct Mag: 1500 x

Cal: 0.006365  $\mu\text{m}/\text{pix}$   
09:27 2023-05-30  
TEM Mode: Imaging  
Microscopist: Andreas Saldivar  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above



646090 FDA\_001.jpg  
646090-1A  
Mica

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

09:25 2023-05-30  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Mica Particle Pictured Above




646090 FDA\_003.jpg  
646090-1A  
Mica


0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.006365 µm/pix  
09:36 2023-05-30  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Chemistry from the Mica Particle Pictured Above



**Asbestos · Lead · Mold · Nano**



646090-1B, Elongated Mica Particle



646090 FDA\_016.jpg  
646090-1B  
Elongated Mica

Cal: 0.001612  $\mu\text{m}/\text{pix}$   
16:39 2023-05-30  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

500 nm  
HV=80kV  
Direct Mag: 6000 x

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Elongated Mica Particle Pictured Above




646090 FDA\_015.jpg  
646090-1B  
Elongated Mica

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.003819 µm/pix  
16:38 2023-05-30  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Mica Particle Pictured Above



Asbestos · Lead · Mold · Nano



646090-1C, Elongated Mica Particle



646090 FDA\_020.jpg  
646090-1C  
Mica

Cal: 0.003183  $\mu\text{m}/\text{pix}$   
10:55 2023-05-31  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 3000 x

Diffraction Pattern from the Elongated Mica Particle Pictured Above




646090 FDA\_019.jpg  
646090-1C  
Mica

10:53 2023-05-31  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Elongated Mica Particle Pictured Above



646090-1A, Iron Particle(s)




646090 FDA\_006.jpg  
646090-1A  
Iron particles

Cal: 0.000626  $\mu\text{m}/\text{pix}$   
09:41 2023-05-30  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=80kV  
Direct Mag: 15000 x

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Iron Particle(s) Pictured Above




646090 FDA\_005.jpg  
646090-1A  
Iron particles

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.004774 μm/pix  
09:39 2023-05-30  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Iron Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-1A, Elongated Iron Particle




646090 FDA\_008.jpg  
646090-1A  
Fe fiber

200 nm  
HV=80kV  
Direct Mag: 10000 x


Cal: 0.000955  $\mu\text{m}/\text{pix}$   
10:16 2023-05-30  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Iron Particle Pictured Above



**Asbestos · Lead · Mold · Nano**

646090-1A, Titanium Particle




646090 FDA\_010.jpg  
646090-1A  
Si Ti particle

1  $\mu$ m  
HV=80kV  
Direct Mag: 2000 x


Cal: 0.004774  $\mu$ m/pix  
11:08 2023-05-30  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Titanium Pictured Above



Asbestos · Lead · Mold · Nano

646090-1B, Elongated Titanium Particle




646090 FDA\_018.jpg  
646090-1B  
Ti Fiber

Cal: 0.006365  $\mu\text{m}/\text{pix}$   
16:49 2023-05-30  
TEM Mode: Imaging  
Microscopist: [i] [e]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

2  $\mu\text{m}$   
HV=80kV  
Direct Mag: 1500 x

Diffraction Pattern from the Elongated Titanium Particle Pictured Above




646090 FDA\_017.jpg  
646090-1B  
Ti Fiber

Cal: 0.001612  $\mu\text{m}/\text{pix}$   
16:46 2023-05-30  
TEM Mode: Diffraction  
Microscopist: [i] [e]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Elongated Titanium Particle Pictured Above



646090-1B, Carbon Particles




646090 FDA\_014.jpg  
646090-1B  
C particles

Cal: 0.003819  $\mu\text{m}/\text{pix}$   
15:23 2023-05-30  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 2500 x

Asbestos · Lead · Mold · Nano

Diffraction Pattern from the Carbon Particle Pictured Above




646090 FDA\_013.jpg  
646090-1B  
C particles

Cal: 0.003819  $\mu\text{m}/\text{pix}$   
15:21 2023-05-30  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Chemistry from the Carbon Particle Pictured Above



Asbestos · Lead · Mold · Nano



646090-1A, Silicon Particle




646090 FDA\_007.jpg  
646090-1A  
Si particles

200 nm  
HV=80kV  
Direct Mag: 15000 x


Cal: 0.000626 µm/pix  
09:43 2023-05-30  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Silicon Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-1A, Talc Particle




646090 FDA\_009.jpg  
646090-1A  
Talc with some embedded iron particles

1  $\mu$ m  
HV=80kV  
Direct Mag: 2000 x


Cal: 0.004774  $\mu$ m/pix  
10:40 2023-05-30  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS5, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-1B, Talc Particle with Iron




646090 FDA\_012.jpg  
646090-1B  
Talc Particle w/Fe particles

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 2500 x

Cal: 0.003819  $\mu\text{m}/\text{pix}$   
14:49 2023-05-30  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Talc with Iron Particle Referenced Above




646090 FDA\_011.jpg  
646090-1B  
Talc Particle w/Fe particles

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

14:47 2023-05-30  
TEM Mode: Diffraction  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle with Iron Referenced Above



646090-2A, 2B, 2C/Client Sample: 04032023-2

**PLM**  
All three aliquots of sample 04032023-2 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-2A | No Asbestos Detected |
| 646090-2B | No Asbestos Detected |
| 646090-2C | No Asbestos Detected |


**TEM**  
(b) (6) analyzed aliquot 2A on June 1, 2023. (b) (6) analyzed aliquot 2B on May 31, 2023, and aliquot 2C on June 6, 2023. The primary particle observed was mica; talc particles, iron particles, silica spheres, and titanium particles area also observed along with talc ribbons/fibers, and particles containing phosphorus and Calcium. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-2A | No Asbestos Detected |
| 646090-2B | No Asbestos Detected |
| 646090-2C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**

646090-2A, Mica Particle




646090 FDA\_002.jpg  
646090-2A  
Mica Particle

600 nm  
HV=100kV  
Direct Mag: 4800 x

Cal: 0.002145  $\mu\text{m}/\text{pix}$   
18:16 2023-06-01  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above




646090 FDA\_001.jpg  
646090-2A  
Mica Particle

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


18:15 2023-06-01  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Mica Particle Pictured Above



646090-2A, Mica Particle



646090 FDA\_008.jpg  
646090-2A  
Mica Particle

Cal: 0.005419  $\mu\text{m}/\text{pix}$   
18:28 2023-06-01  
TEM Mode: Imaging  
Microscopist(B) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 1900 x

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above




646090 FDA\_007.jpg  
646090-2A  
Mica Particle

Cal: 0.001030  $\mu\text{m}/\text{pix}$   
18:27 2023-06-01  
TEM Mode: Diffraction  
Microscopist(b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

Chemistry from the Mica Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-2A, Talc Particle




646090 FDA\_014.jpg  
646090-2A  
Talc Particle

800 nm  
HV=100kV  
Direct Mag: 3600 x

Cal: 0.002860  $\mu\text{m}/\text{pix}$   
18:46 2023-06-01  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above



646090 FDA\_013.jpg  
646090-2A  
Talc Particle


0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.001030  $\mu\text{m}/\text{pix}$   
18:42 2023-06-01  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


**Asbestos · Lead · Mold · Nano**



Chemistry from the Talc Particle Pictured Above



646090-2A, Iron Particles




646090 FDA\_009.jpg  
646090-2A  
Fe particles

Cal: 0.002145  $\mu\text{m}/\text{pix}$   
18:32 2023-06-01  
TEM Mode: Imaging  
Microscopist: [B] [E]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

600 nm  
HV=100kV  
Direct Mag: 4800 x

**Asbestos · Lead · Mold · Nano**

Chemistry from the Iron Particles Pictured Above



646090-2A, Elongated Iron Particle



646090 FDA\_006.jpg  
646090-2A  
Fe Fiber

200 nm  
HV=100kV  
Direct Mag: 10000 x

Cal: 0.001030  $\mu\text{m}/\text{pix}$   
18:23 2023-06-01  
TEM Mode: Imaging  
Microscopist®  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Asbestos • Lead • Mold • Nano

Diffraction Pattern from the Elongated Iron Particle Pictured Above




646090 FDA\_005.jpg  
646090-2A  
Fe Fiber

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.005419 μm/pix  
18:22 2023-06-01  
TEM Mode: Diffraction  
Microscopist (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Iron Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-2A, Silica Sphere




646090 FDA\_011.jpg  
646090-2A  
Silica Sphere

1  $\mu$ m  
HV=100kV  
Direct Mag: 1900 x


Cal: 0.005419  $\mu$ m/pix  
18:35 2023-06-01  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

*Chemistry from the Silica Sphere Pictured Above*



**Asbestos · Lead · Mold · Nano**

646090-2A, Titanium Particles



646090 FDA\_016.jpg  
646090-2A  
Ti particles

Cal: 0.001430  $\mu\text{m}/\text{pix}$   
19:06 2023-06-01  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

400 nm  
HV=100kV  
Direct Mag: 7200 x

Diffraction Pattern from the Titanium Particles Pictured Above




646090 FDA\_015.jpg  
646090-2A  
Ti particles

Cal: 0.002860  $\mu\text{m}/\text{pix}$   
19:05 2023-06-01  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Titanium Particles Pictured Above



646090-2A, Talc Ribbon




646090 FDA\_018.jpg  
646090-2A  
Talc Ribbon

Cal: 0.007355 µm/pix  
19:15 2023-06-01  
TEM Mode: Imaging  
Microscopist: [E]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

2 µm  
HV=100kV  
Direct Mag: 1400 x

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Talc Ribbon Pictured Above




646090 FDA\_017.jpg  
646090-2A  
Talc Ribbon

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.001430 μm/pix  
19:13 2023-06-01  
TEM Mode: Diffraction  
Microscopist (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Talc Ribbon Pictured Above



Asbestos · Lead · Mold · Nano

646090-2A, Elongated Talc Particle



646090 FDA\_004.jpg  
646090-2A  
Talc Fiber

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 1900 x

Cal: 0.005419  $\mu\text{m}/\text{pix}$   
18:20 2023-06-01  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Elongated Talc Pictured Above



646090 FDA\_003.jpg  
646090-2A  
Talc Fiber


0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.002145  $\mu\text{m}/\text{pix}$   
18:19 2023-06-01  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


**Asbestos · Lead · Mold · Nano**



Chemistry from the Elongated Talc Particle Pictured Above



646090-2A, Particle Containing Phosphorus and Calcium




646090 FDA\_012.jpg  
646090-2A  
P,Ca particle

Cal: 0.001030  $\mu\text{m}/\text{pix}$   
18:39 2023-06-01  
TEM Mode: Imaging  
Microscopist: [REDACTED]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


200 nm  
HV=100kV  
Direct Mag: 10000 x

**Asbestos · Lead · Mold · Nano**

Chemistry from the Particle Containing Phosphorus and Calcium Pictured Above



646090-2B, Particle Containing Potassium, Oxygen, Magnesium, Aluminum, Silicon, Calcium, Barium, and Manganese




646090 FDA\_021.jpg  
646090-2B  
Na,Al,Si... Fiber  
Cal: 0.001905  $\mu\text{m}/\text{pix}$   
12:46 2023-06-02  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

600 nm  
HV=80kV  
Direct Mag: 5000 x

**Asbestos · Lead · Mold · Nano**

Chemistry from the Particle Containing Potassium, Oxygen, Magnesium, Aluminum, Silicon, Calcium, Barium, and Manganese Pictured Above



646090-3A, 3B, 3C/Client Sample: 04032023-3

**PLM**  
All three aliquots of sample 04032023-3 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-3A | No Asbestos Detected |
| 646090-3B | No Asbestos Detected |
| 646090-3C | No Asbestos Detected |


**TEM**  
(b) (6) analyzed aliquot 3A on June 5, 2023. (b) (6) analyzed aliquot 3B on June 6, 2023, and aliquot 3C on June 7, 2023. The primary particle observed was iron; mica particles with titanium and iron were also observed along with silicon and talc particles. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-3A | No Asbestos Detected |
| 646090-3B | No Asbestos Detected |
| 646090-3C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**

646090-3A, Iron Particles




646090 FDA\_023.jpg  
646090-3A  
Fe Particles

Cal: 0.000955  $\mu\text{m}/\text{pix}$   
15:49 2023-06-05  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=80kV  
Direct Mag: 10000 x

Diffraction Pattern from the Iron Particles Pictured Above




646090 FDA\_022.jpg  
646090-3A  
Fe Particles

15:47 2023-06-05  
TEM Mode: Diffraction  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Iron Particles Pictured Above



646090-3A, Elongated Iron Particle




646090 FDA\_026.jpg  
646090-3A  
Fe Fiber

Cal: 0.000817  $\mu\text{m}/\text{pix}$   
15:51 2023-06-05  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=80kV  
Direct Mag: 12000 x

Asbestos · Lead · Mold · Nano

Diffraction Pattern from the Elongated Iron Particle Pictured Above




646090 FDA\_024.jpg  
646090-3A  
Fe Fiber

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.000955 μm/pix  
15:49 2023-06-05  
TEM Mode: Diffraction  
Microscopist@  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Iron Particles Pictured Above



Asbestos · Lead · Mold · Nano

646090-3A, Mica Particle with Iron and Titanium




646090 FDA\_028.jpg  
646090-3A  
Mica w/ Ti, Fe

Cal: 0.007956  $\mu\text{m}/\text{pix}$   
15:56 2023-06-05  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

2  $\mu\text{m}$   
HV=80kV  
Direct Mag: 1200 x

Diffraction Pattern from the Mica Particle with Iron and Titanium Pictured Above




646090 FDA\_027.jpg  
646090-3A  
Mica w/ Ti, Fe

Cal: 0.000817  $\mu\text{m}/\text{pix}$   
15:55 2023-06-05  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Mica Particle with Iron and Titanium Pictured Above



646090-3A, Mica Particle with Iron and Titanium




646090 FDA\_032.jpg  
646090-3A  
Mica w/ Ti, Fe  
Cal: 0.006365  $\mu\text{m}/\text{pix}$   
16:23 2023-06-05  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

2  $\mu\text{m}$   
HV=80kV  
Direct Mag: 1500 x

**Asbestos · Lead · Mold · Nano**




Hexagonal Diffraction Pattern from the Mica Particle with Iron and Titanium Pictured Above




646090 FDA\_031.jpg  
646090-3A  
Mica w/ Ti, Fe  
0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.002387 µm/pix  
16:16 2023-06-05  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Mica Particle with Iron and Titanium Pictured Above



Asbestos · Lead · Mold · Nano

646090-3A, Silicon Particle




646090 FDA\_033.jpg  
646090-3A  
Si Particle

500 nm  
HV=80kV  
Direct Mag: 6000 x


Cal: 0.001612  $\mu\text{m}/\text{pix}$   
16:50 2023-06-05  
TEM Mode: Imaging  
Microscopist<sup>®</sup> (B)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Silicon Particle Pictured Above



Asbestos • Lead • Mold • Nano

646090-3A, Talc Particle




646090 FDA\_030.jpg  
646090-3A  
Talc Particle

600 nm  
HV=80kV  
Direct Mag: 4000 x

Cal: 0.002387  $\mu\text{m}/\text{pix}$   
16:07 2023-06-05  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_029.jpg  
646090-3A  
Talc Particle

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.007956  $\mu\text{m}/\text{pix}$   
16:06 2023-06-05  
TEM Mode: Diffraction  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle Pictured Above



646090-3C, Particle Containing Aluminum and Iron




646090 FDA\_076.tif  
646090-3C  
Fe,Al particulate

200 nm  
HV=80kV  
Direct Mag: 12000 x

Cal: 0.000817  $\mu\text{m}/\text{pix}$   
13:56 2023-06-08  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Particle Containing Aluminum and Iron Pictured Above



646090-4A, 4B, 4C/Client Sample: 04032023-4

**PLM**  
All three aliquots of sample 04032023-4 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-4A | No Asbestos Detected |
| 646090-4B | No Asbestos Detected |
| 646090-4C | No Asbestos Detected |


**TEM**  
(b) (6) analyzed aliquot 4A on June 7, 2023. (b) (6) analyzed aliquot 4B on June 7, 2023, and (b) (6) analyzed aliquot 4C on June 8, 2023. The primary particle observed was talc; titanium and iron particles were also observed along with calcium particles, silicon particles, aluminum particles, talc ribbons/fibers, particles containing phosphorus and calcium, and particles containing magnesium, aluminum, silicon, and iron. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-4A | No Asbestos Detected |
| 646090-4B | No Asbestos Detected |
| 646090-4C | No Asbestos Detected |

Asbestos · Lead · Mold · Nano


Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

646090-4A, Talc Particle



646090 FDA\_034.jpg  
646090-4A  
Talc  
200 nm  
HV=80kV  
Direct Mag: 12000 x  
Cal: 0.000817  $\mu\text{m}/\text{pix}$   
09:56 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_035.jpg  
646090-4A  
Talc  
0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.000817  $\mu\text{m}/\text{pix}$   
09:59 2023-06-07  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle Pictured Above



646090-4A, Talc Particle




646090 FDA\_037.jpg  
646090-4A  
Talc

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
10:04 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

400 nm  
HV=80kV  
Direct Mag: 8000 x


**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above



646090 FDA\_036.jpg  
646090-4A  
Talc  
0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.000817 µm/pix  
10:01 2023-06-07  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Chemistry from the Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano




646090-4A, Talc Particle



646090 FDA\_042.jpg  
646090-4A  
Talc  
Dense particles  
Cal: 0.015913  $\mu\text{m}/\text{pix}$   
10:19 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

4  $\mu\text{m}$   
HV=80kV  
Direct Mag: 600 x

*Diffraction Pattern from the Talc Particle Pictured Above*




646090 FDA\_041.jpg  
646090-4A  
Talc  
Cal: 0.000477  $\mu\text{m}/\text{pix}$   
10:16 2023-06-07  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 600 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle Pictured Above



646090-4A, Titanium Particles




646090 FDA\_038.jpg  
646090-4A  
Titanium particles

Cal: 0.000477  $\mu\text{m}/\text{pix}$   
10:07 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

100 nm  
HV=80kV  
Direct Mag: 20000 x


**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Titanium Particles Pictured Above




646090 FDA\_039.jpg  
646090-4A  
Titanium particles  
0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.000477 μm/pix  
10:08 2023-06-07  
TEM Mode: Diffraction  
Microscopist (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Titanium Particles Pictured Above



Asbestos · Lead · Mold · Nano

646090-4A, Titanium Particle




646090 FDA\_045.jpg  
646090-4A  
Titanium particles

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
10:30 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

400 nm  
HV=80kV  
Direct Mag: 8000 x

Diffraction Pattern from the Titanium Particle Pictured Above




646090 FDA\_046.jpg  
646090-4A  
Titanium particles

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
10:32 2023-06-07  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Titanium Particle Pictured Above




646090-4A, Elongated Titanium Particle



646090 FDA\_050.jpg  
646090-4A  
Titanium fiber  
600 nm  
HV=80kV  
Direct Mag: 5000 x  
Cal: 0.001905 µm/pix  
11:39 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Asbestos · Lead · Mold · Nano

Diffraction Pattern from the Elongated Titanium Particle Pictured Above




646090 FDA\_049.jpg  
646090-4A  
Titanium fiber  
0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.001209 µm/pix  
11:38 2023-06-07  
TEM Mode: Diffraction  
Microscopist (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Titanium Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-4A, Iron Particles




646090 FDA\_044.jpg  
646090-4A  
Fe particles

100 nm  
HV=80kV  
Direct Mag: 20000 x

Cal: 0.000477  $\mu\text{m}/\text{pix}$   
10:24 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

*Diffraction Pattern from the Iron Particles Pictured Above*




646090 FDA\_043.jpg  
646090-4A  
Fe particles

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.015913  $\mu\text{m}/\text{pix}$   
10:22 2023-06-07  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Iron Particles Pictured Above



646090-4C, Iron Particles



646090\_025.tif  
Fe part

Cal: 0.001030  $\mu\text{m}/\text{pix}$   
18:38 2023-06-08  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=100kV  
Direct Mag: 10000 x

**Asbestos · Lead · Mold · Nano**



Diffraction Pattern from the Iron Particles Pictured Above




646090\_024.tif  
Fe part

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


18:35 2023-06-08  
TEM Mode: Diffraction  
Microscopist(B) (E)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Iron Particles Pictured Above



Asbestos · Lead · Mold · Nano

646090-4B, Calcium Particles




646090 FDA\_019.jpg  
646090-4B  
Ca Particle

400 nm  
HV=100kV  
Direct Mag: 7200 x

Cal: 0.001430  $\mu\text{m}/\text{pix}$   
16:32 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Calcium Particles Pictured Above




646090 FDA\_020.jpg  
646090-4B  
Ca Particle

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.001430  $\mu\text{m}/\text{pix}$   
16:33 2023-06-07  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Calcium Particles Pictured Above



646090-4C, Silicon Particle




646090\_026.tif  
Si part

Cal: 0.001430  $\mu\text{m}/\text{pix}$   
18:47 2023-06-08  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


400 nm  
HV=100kV  
Direct Mag: 7200 x

**Asbestos · Lead · Mold · Nano**

Chemistry from the Aluminum Particle Pictured Above



646090-4B, Aluminum Particle




646090 FDA\_021.tif  
646090-4B  
Al Particle

Cal: 0.001030  $\mu\text{m}/\text{pix}$   
16:45 2023-06-07  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


200 nm  
HV=100kV  
Direct Mag: 10000 x

**Asbestos · Lead · Mold · Nano**

Chemistry from the Aluminum Particle Pictured Above



646090-4A, Elongated Talc Particle



646090 FDA\_048.jpg  
646090-4A  
Elongated talc particle

400 nm  
HV=80kV  
Direct Mag: 8000 x

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
10:38 2023-06-07  
TEM Mode: Imaging  
Microscopist: (b) (6)

Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_047.jpg  
646090-4A  
Elongated talc particle

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.001209 µm/pix  
10:37 2023-06-07  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Talc Particle Pictured Above



Asbestos • Lead • Mold • Nano

646090-4A, Particle Containing Phosphorus and Calcium




646090 FDA\_040.jpg  
646090-4A  
C,P,Ca particle

100 nm  
HV=80kV  
Direct Mag: 20000 x


Cal: 0.000477  $\mu\text{m}/\text{pix}$   
10:12 2023-06-07  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Phosphorus and Calcium Pictured Above



**Asbestos · Lead · Mold · Nano**

646090-4B, Particle Containing Magnesium, Aluminum, Silicon, and Iron




646090\_023.tif  
646090-4B FDA  
Mg, Al, Si, Fe Particle

400 nm  
HV=100kV  
Direct Mag: 7200 x

Cal: 0.001430 µm/pix  
10:18 2023-06-08  
TEM Mode: Imaging  
Microscopist: [Logo]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above



**Asbestos · Lead · Mold · Nano**



646090-5A, 5B, 5C/Client Sample: 04032023-5

*PLM*  
All three aliquots of sample 04032023-5 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.


|           |                      |
|-----------|----------------------|
| 646090-5A | No Asbestos Detected |
| 646090-5B | No Asbestos Detected |
| 646090-5C | No Asbestos Detected |

*TEM*  
(b) (6) analyzed aliquot 5A on June 7, 2023, and aliquot 5C on June 9, 2023. (b) (6) analyzed aliquot 5B on June 9, 2023. The primary particle observed was talc; talc ribbons/fibers were also observed along with mica "like" particles, titanium particles, calcium particles, particles containing phosphorous and calcium, and particles containing magnesium, aluminum, silicon and iron. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-5A | No Asbestos Detected |
| 646090-5B | No Asbestos Detected |
| 646090-5C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.


646090-5A, Talc Particle



646090 FDA\_052.jpg  
646090-5A  
Talc Particle  
600 nm  
HV=80kV  
Direct Mag: 4000 x  
Cal: 0.002387 µm/pix  
12:37 2023-06-07  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_051.jpg  
646090-5A  
Talc Particle

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


12:36 2023-06-07  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-5A, Talc Ribbon




646090 FDA\_056.jpg  
646090-5A  
Talc Ribbon

Cal: 0.004774  $\mu\text{m}/\text{pix}$   
12:53 2023-06-07  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 2000 x

*Diffraction Pattern from the Talc Ribbon Pictured Above*




646090 FDA\_055.jpg  
646090-5A  
Talc Ribbon

Cal: 0.001905  $\mu\text{m}/\text{pix}$   
12:52 2023-06-07  
TEM Mode: Diffraction  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Ribbon Pictured Above



646090-5A, Elongated Talc Particle




646090 FDA\_059.jpg  
646090-5A  
Talc Fiber

Cal: 0.003819  $\mu\text{m}/\text{pix}$   
13:07 2023-06-07  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 2500 x

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_058.jpg  
646090-5A  
Talc Fiber

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.003183 µm/pix  
13:06 2023-06-07  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-5A, Particle Containing Sodium, Magnesium, Potassium, and Calcium




646090 FDA\_054.jpg  
646090-5A  
Na,Mg,Si,K,Ca

600 nm  
HV=80kV  
Direct Mag: 5000 x


Cal: 0.001905 µm/pix  
12:49 2023-06-07  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Sodium, Magnesium, Potassium, and Calcium Pictured Above



Asbestos · Lead · Mold · Nano

646090-5A, Elongated Titanium Particle




646090 FDA\_057.jpg  
646090-5A  
Ti Fiber

1  $\mu$ m  
HV=80kV  
Direct Mag: 3000 x


Cal: 0.003183  $\mu$ m/pix  
12:58 2023-06-07  
TEM Mode: Imaging  
Microscopist<sup>®</sup> (B)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Titanium Particle Pictured Above



Asbestos • Lead • Mold • Nano

646090-5A, Calcium Particle




646090 FDA\_061.jpg  
646090-5A  
Ca particle

Cal: 0.000817  $\mu\text{m}/\text{pix}$   
13:11 2023-06-07  
TEM Mode: Imaging  
Microscopist<sup>®</sup> (B)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=80kV  
Direct Mag: 12000 x

Diffraction Pattern from the Calcium Particle Pictured Above



646090 FDA\_060.jpg  
646090-5A  
Ca particle


Cal: 0.003819  $\mu\text{m}/\text{pix}$   
13:11 2023-06-07  
TEM Mode: Diffraction  
Microscopist<sup>®</sup> (B)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


**Asbestos · Lead · Mold · Nano**



Chemistry from the Calcium Particle Pictured Above



646090-5A, Particle Containing Phosphorus and Calcium




646090 FDA\_053.jpg  
646090-5A  
P,Ca Particle

500 nm  
HV=80kV  
Direct Mag: 6000 x


Cal: 0.001612  $\mu\text{m}/\text{pix}$   
12:43 2023-06-07  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Particle Containing Phosphorus and Calcium Pictured Above



646090-5C, Particle Containing Magnesium, Aluminum, Silicon, and Iron




646090 FDA\_076.jpg  
646090-5C  
Mg,Al,Si,Fe particle  
Cal: 0.003819  $\mu\text{m}/\text{pix}$   
16:28 2023-06-09  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 2500 x

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above




646090 FDA\_075.jpg  
646090-5C  
Mg,Al,Si,Fe particle

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m

16:26 2023-06-09  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above



Asbestos · Lead · Mold · Nano

646090-6A, 6B, 6C/Client Sample: 04032023-6

**PLM**  
All three aliquots of sample 04032023-6 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.


|           |                      |
|-----------|----------------------|
| 646090-6A | No Asbestos Detected |
| 646090-6B | No Asbestos Detected |
| 646090-6C | No Asbestos Detected |

**TEM**  
(b) (6) analyzed aliquot 6A on June 8, 2023. (b) (6) analyzed aliquot 6B on June 13, 2023, and (b) (6) analyzed aliquot 6C on June 14, 2023. The primary particle observed was talc; mica particles and talc ribbons/fibers were also observed along with silicon particles, particles containing sodium, aluminum, silicon, and iron, particles containing magnesium, aluminum, and silicon, silica spheres with aluminum and chromium, and particles containing magnesium, aluminum, silicon, and iron. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-6A | No Asbestos Detected |
| 646090-6B | No Asbestos Detected |
| 646090-6C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.


646090-6A, Talc Particle



646090 FDA\_068.jpg  
646090-6A  
Talc Particle  
600 nm  
HV=80kV  
Direct Mag: 5000 x  
Cal: 0.001905 µm/pix  
11:44 2023-06-08  
TEM Mode: Imaging  
Microscopist (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




846090 FDA\_067.jpg  
846090-6A  
Talc Particle  
Cal: 0.000955  $\mu\text{m}/\text{pix}$   
11:43 2023-06-08  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast  
0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

Chemistry from the Talc Particle Pictured Above



646090-6A, Mica Particle

**Asbestos · Lead · Mold · Nano**




646090 FDA\_070.jpg  
646090-6A  
Mica Particle

Cal: 0.003183  $\mu\text{m}/\text{pix}$   
11:49 2023-06-08  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 3000 x

*Diffraction Pattern from the Mica Particle Pictured Above*




646090 FDA\_069.jpg  
646090-6A  
Mica Particle

Cal: 0.001905  $\mu\text{m}/\text{pix}$   
11:48 2023-06-08  
TEM Mode: Diffraction  
Microscopist: [signature]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

*Chemistry from the Mica Particle Pictured Above*

**Asbestos · Lead · Mold · Nano**



646090-6A, Talc Ribbon




646090 FDA\_072.jpg  
646090-6A  
Talc Ribbon

Cal: 0.001905  $\mu\text{m}/\text{pix}$   
12:21 2023-06-08  
TEM Mode: imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

600 nm  
HV=80kV  
Direct Mag: 5000 x


Diffraction Pattern from the Talc Ribbon Pictured Above

**Asbestos · Lead · Mold · Nano**



646090 FDA\_073.jpg  
646090-6A  
Talc Ribbon  
0.2 Å  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.001905 µm/pix  
12:22 2023-06-08  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


*Chemistry from the Talc Ribbon Pictured Above*



646090-6A Elongated Talc Particle

**Asbestos · Lead · Mold · Nano**






646090 FDA\_063.jpg  
646090-6A  
Talc Fiber

Cal: 0.003183  $\mu\text{m}/\text{pix}$   
11:20 2023-06-08  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 3000 x

*Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above*




646090 FDA\_062.jpg  
646090-6A  
Talc Fiber

Cal: 0.000817  $\mu\text{m}/\text{pix}$   
11:19 2023-06-08  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

*Chemistry from the Elongated Talc Particle Pictured Above*

**Asbestos · Lead · Mold · Nano**



646090-6A Silicon Particle




646090 FDA\_064.jpg  
646090-6A  
SI Particle

Cal: 0.001612  $\mu\text{m}/\text{pix}$   
11:24 2023-06-08  
TEM Mode: imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


500 nm  
HV=80kV  
Direct Mag: 6000 x

Chemistry from the Silicon Particle Pictured Above

**Asbestos · Lead · Mold · Nano**



646090-6A Particle Containing Sodium, Aluminum, Silicon, and Iron




646090 FDA\_066.jpg  
646090-6A  
O,Na,Al,Si,Fe particle

Cal: 0.000955  $\mu\text{m}/\text{pix}$   
11:37 2023-06-08  
TEM Mode: imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


200 nm  
HV=80kV  
Direct Mag: 10000 x

Chemistry from the Particle Containing Sodium, Aluminum, Silicon, and Iron Pictured Above

**Asbestos · Lead · Mold · Nano**



646090-6A Particle Containing Magnesium, Aluminum, Silicon, Calcium, and Iron




646090 FDA\_065.jpg  
646090-6A  
O,Mg,Al,Si,S,Ca,Fe particle

500 nm  
HV=80kV  
Direct Mag: 6000 x


Cal: 0.001612  $\mu\text{m}/\text{pix}$   
11:33 2023-06-08  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Magnesium, Aluminum, Silicon, Calcium, and Iron Pictured Above

**Asbestos • Lead • Mold • Nano**



646090-6A Particle Containing Aluminum, Silicon, and Iron




646090 FDA\_071.jpg  
646090-6A  
Al,Si,Fe particle

Cal: 0.001612  $\mu\text{m}/\text{pix}$   
12:12 2023-06-08  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


500 nm  
HV=80kV  
Direct Mag: 6000 x

Chemistry from the Particle Containing Aluminum, Silicon, and Iron Pictured Above

**Asbestos · Lead · Mold · Nano**



646090-6A Silica Spheres with Aluminum and Chromium




646090 FDA\_074.jpg  
646090-6A  
O,Al,Si,Cr Sphere

Cal: 0.001905  $\mu\text{m}/\text{pix}$   
12:29 2023-06-08  
TEM Mode: imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


600 nm  
HV=80kV  
Direct Mag: 5000 x

Chemistry from the Silica Spheres with Aluminum and Chromium Pictured Above

**Asbestos • Lead • Mold • Nano**



646090-6B, Particle Containing Aluminum, Silicon, and Titanium




Ti part.tif  
Ti Part  
Cal: 0.002860  $\mu\text{m}/\text{pix}$   
17:27 2023-06-13  
TEM Mode: Imaging  
Microscopist®  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


800 nm  
HV=100kV  
Direct Mag: 3600 x

Chemistry from the Particle Containing Aluminum, Silicon, and Titanium Pictured Above

**Asbestos · Lead · Mold · Nano**




646090-6B, Particle Containing Magnesium, Aluminum, Silicon, and Iron



Chemistry from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above

**Asbestos · Lead · Mold · Nano**





646090-7A, 7B, 7C/Client Sample: 04032023-7

**PLM**  
All three aliquots of sample 04032023-7 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-7A | No Asbestos Detected |
| 646090-7B | No Asbestos Detected |
| 646090-7C | No Asbestos Detected |


**TEM**  
(b) (6) analyzed aliquot 7A on June 12, 2023. (b) (6) analyzed aliquot 7B and June 12, 2023 and (b) (6) analyzed aliquot 7C on June 12, 2023. The primary particle observed was titanium; mica and talc particles were also observed along with talc ribbons/fibers, iron particles, and particles containing magnesium, aluminum, and silicon. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-7A | No Asbestos Detected |
| 646090-7B | No Asbestos Detected |
| 646090-7C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**

646090-7A, Titanium Particles



646090 FDA\_022.jpg  
646090-7A  
Ti Particles

400 nm  
HV=100kV  
Direct Mag: 7200 x

Cal: 0.001430  $\mu\text{m}/\text{pix}$   
17:20 2023-06-12  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Titanium Particles Pictured Above




646090 FDA\_021.jpg  
646090-7A  
Ti Particles

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


17:18 2023-06-12  
TEM Mode: Diffraction  
Microscopist(b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Titanium Particles Pictured Above



646090-7A, Mica Particle




646090 FDA\_024.jpg  
646090-7A  
Mica Particle

Cal: 0.002145  $\mu\text{m}/\text{pix}$   
17:26 2023-06-12  
TEM Mode: Imaging  
Microscopist(B)(6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

600 nm  
HV=100kV  
Direct Mag: 4800 x

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above




646090 FDA\_023.jpg  
646090-7A  
Mica Particle

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.001430 µm/pix  
17:25 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Mica Particle Pictured Above



**Asbestos · Lead · Mold · Nano**

646090-7A, Talc Particle



646090 FDA\_026.jpg  
646090-7A  
Talc Particle

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 2900 x

Cal: 0.003702  $\mu\text{m}/\text{pix}$   
17:30 2023-06-12  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_025.jpg  
646090-7A  
Talc Particle

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.002145  $\mu\text{m}/\text{pix}$   
17:30 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle Pictured Above



646090-7A, Talc Ribbon




646090 FDA\_030.jpg  
646090-7A  
Talc Ribbon

Cal: 0.003702  $\mu\text{m}/\text{pix}$   
18:04 2023-06-12  
TEM Mode: Imaging  
Microscopist: [REDACTED]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 2900 x

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Talc Ribbon Pictured Above




646090 FDA\_029.jpg  
646090-7A  
Talc Ribbon

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.001775 µm/pix  
18:03 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Talc Ribbon Pictured Above



**Asbestos · Lead · Mold · Nano**

646090-7A, Elongated Talc Particle




646090 FDA\_028.jpg  
646090-7A  
Talc Fiber

500 nm  
HV=100kV  
Direct Mag: 5800 x

Cal: 0.001775  $\mu\text{m}/\text{pix}$   
17:48 2023-06-12  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above



646090 FDA\_027.jpg  
646090-7A  
Talc Fiber


0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.003702  $\mu\text{m}/\text{pix}$   
17:47 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


**Asbestos · Lead · Mold · Nano**



Chemistry from the Elongated Talc Particle Pictured Above



646090-7B, Iron Particle




646090 FDA-049.tif  
646090-7B  
Fe Particle

Cal: 0.001030 µm/pix  
12:17 2023-06-14  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=100kV  
Direct Mag: 10000 x

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Iron Particle Pictured Above




646090 FDA\_048.tif  
646090-7B  
Fe Particle Diffraction

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


12:14 2023-06-14  
TEM Mode: Diffraction  
Microscopist: MM  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Iron Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-7B, Elongated Particle Containing Magnesium, Aluminum, and Iron




646090 FDA\_051.tif  
646090-7B  
Mg, Al, Si Particle

400 nm  
HV=100kV  
Direct Mag: 7200 x

Cal: 0.001430  $\mu\text{m}/\text{pix}$   
14:21 2023-06-14  
TEM Mode: Imaging  
Microscopist: MM  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Particle Containing Magnesium, Aluminum, and Iron Pictured Above



Asbestos · Lead · Mold · Nano

646090-8A, 8B, 8C/Client Sample: 04032023-8

**PLM**  
All three aliquots of sample 04032023-8 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.


|           |                      |
|-----------|----------------------|
| 646090-8A | No Asbestos Detected |
| 646090-8B | No Asbestos Detected |
| 646090-8C | No Asbestos Detected |

**TEM**  
(b) (6) analyzed aliquot 8A on June 12, 2023. (b) (6) analyzed aliquots 8B and 8C on June 14, 2023. The primary particle observed was talc; silicon particles were also observed along with mica particles, silica spheres, talc ribbons/fibers, and particles containing phosphorus, sulfur, and calcium. A single (1) tremolite particle was observed on aliquot 8A and two (2) tremolite particles were observed on aliquot 8C. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-8A | < 0.01873%           |
| 646090-8B | No Asbestos Detected |
| 646090-8C | < 0.00348%           |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.


646090-8A, Talc Particle



646090 FDA\_037.jpg  
646090-8A  
Talc Particle  
Cat: 0.005419 µm/pix  
18:29 2023-06-12  
TEM Mode: Imaging  
Microscopist (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast  
1 µm  
HV=100kV  
Direct Mag: 1900 x

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_036.jpg  
646090-8A  
Talc Particle

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.005419 µm/pix  
18:28 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-8A, Silicon Particle




646090 FDA\_040.jpg  
646090-8A  
Si particle

500 nm  
HV=100kV  
Direct Mag: 5800 x

Cal: 0.001775  $\mu\text{m}/\text{pix}$   
18:36 2023-06-12  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Silicon Particle Pictured Above




646090 FDA\_039.jpg  
646090-8A  
Si particle

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.001775  $\mu\text{m}/\text{pix}$   
18:35 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Silicon Particle Pictured Above



646090-8A, Mica Particle




646090 FDA\_047.jpg  
646090-8A  
Mica particle  
Cal: 0.003702  $\mu\text{m}/\text{pix}$   
19:13 2023-06-12  
TEM Mode: Imaging  
Microscopist(B) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 2900 x

Asbestos · Lead · Mold · Nano

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above




646090 FDA\_046.jpg  
646090-8A  
Mica particle

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.001775 µm/pix  
19:12 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Chemistry from the Mica Pictured Above



Asbestos · Lead · Mold · Nano



646090-8A, Silica Spheres




646090 FDA\_045.jpg  
646090-8A  
silica spheres

500 nm  
HV=100kV  
Direct Mag: 5800 x


Cal: 0.001775  $\mu\text{m}/\text{pix}$   
19:09 2023-06-12  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Silica Spheres Pictured Above



Asbestos · Lead · Mold · Nano

646090-8A, Talc Ribbon




646090 FDA\_042.jpg  
646090-8A  
talc ribbon

800 nm  
HV=100kV  
Direct Mag: 3600 x

Cal: 0.002860  $\mu\text{m}/\text{pix}$   
18:59 2023-06-12  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Talc Ribbon Pictured Above




646090 FDA\_041.jpg  
646090-8A  
talc ribbon

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.001775  $\mu\text{m}/\text{pix}$   
18:58 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Ribbon Pictured Above



646090-8A, Elongated Talc Particle




646090 FDA\_044.jpg  
646090-8A  
talc fiber

1  $\mu$ m  
HV=100kV  
Direct Mag: 2900 x

Cal: 0.003702  $\mu$ m/pix  
19:07 2023-06-12  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_043.jpg  
646090-8A  
talc fiber

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.002860 µm/pix  
19:05 2023-06-12  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-8A, Particle Containing Phosphorus, Sulfur, and Calcium




646090 FDA\_038.jpg  
646090-8A  
P,S,Ca particle

500 nm  
HV=100kV  
Direct Mag: 5800 x


Cal: 0.001775  $\mu\text{m}/\text{pix}$   
18:33 2023-06-12  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Phosphorus, Sulfur, and Calcium Pictured Above



Asbestos · Lead · Mold · Nano

646090-8A, Tremolite Particle



646090 FDA\_048.jpg  
646090-8A  
Tremolite

Cal: 0.005419  $\mu\text{m}/\text{pix}$   
15:53 2023-06-14  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 1900 x

Diffraction Pattern(s) from the Tremolite Particle Pictured Above



646090 FDA\_049.jpg  
646090-8A  
Tremolite

Cal: 0.005419  $\mu\text{m}/\text{pix}$   
15:55 2023-06-14  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

**Asbestos · Lead · Mold · Nano**



646090 FDA\_050.jpg  
646090-8A  
Tremolite

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.005419 µm/pix  
15:56 2023-06-14  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast



646090 FDA\_051.jpg  
646090-8A  
Tremolite

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.005419 µm/pix  
15:57 2023-06-14  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**



646090 FDA\_052.jpg  
646090-8A  
Tremolite

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.005419 µm/pix  
15:58 2023-06-14  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast



646090 FDA\_053.jpg  
646090-8A  
Tremolite


0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.005419 µm/pix  
15:59 2023-06-14  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


**Asbestos · Lead · Mold · Nano**



Chemistry from the Tremolite Particle Pictured Above



646090-8C, Tremolite Particle 1



646090 FDA\_080.jpg  
646090-8C  
Tremolite

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
11:49 2023-06-14  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

400 nm  
HV=80kV  
Direct Mag: 8000 x

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Tremolite Particle Pictured Above




646090 FDA\_079.jpg  
646090-8C  
Tremolite

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.003183 μm/pix  
11:41 2023-06-14  
TEM Mode: Diffraction  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Tremolite Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-8C, Tremolite Particle 2



646090 FDA\_082.jpg  
646090-8C  
Tremolite

400 nm  
HV=80kV  
Direct Mag: 8000 x

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
12:17 2023-06-14  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

*Diffraction Pattern from the Tremolite Particle Pictured Above*




646090 FDA\_081.jpg  
646090-8C  
Tremolite

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
12:16 2023-06-14  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Tremolite Particle Pictured Above



646090-9A, 9B, 9C/Client Sample: 04032023-9

**PLM**  
All three aliquots of sample 04032023-9 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-9A | No Asbestos Detected |
| 646090-9B | No Asbestos Detected |
| 646090-9C | No Asbestos Detected |


**TEM**  
(b) (6) analyzed aliquot 9A on June 15, 2023, and aliquot 9C on June 16, 2023. (b) (6) analyzed aliquot 9B June 16, 2023. The primary particles observed were talc and mica; talc ribbons/fibers and iron particles were also observed along with silica spheres. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-9A | No Asbestos Detected |
| 646090-9B | No Asbestos Detected |
| 646090-9C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**


646090-9A, Talc Particle (Dense)



646090 FDA\_088.jpg  
646090-9A  
Talc  
Dense particle  
Cal: 0.003819  $\mu\text{m}/\text{pix}$   
11:57 2023-06-15  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 2500 x

Diffraction Pattern from the Talc Particle (Dense) Pictured Above




646090 FDA\_089.jpg  
646090-9A  
Talc  
Dense particle  
Cal: 0.003819  $\mu\text{m}/\text{pix}$   
12:02 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle (Dense) Pictured Above



646090-9A, Talc Particle




646090 FDA\_091.jpg  
646090-9A  
Talc

Cal: 0.001905  $\mu\text{m}/\text{pix}$   
12:06 2023-06-15  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

600 nm  
HV=80kV  
Direct Mag: 5000 x

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_090.jpg  
646090-9A  
Talc

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.003819 µm/pix  
12:05 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-9A, Mica Particle



646090 FDA\_084.jpg  
646090-9A  
Mica

Cal: 0.004774  $\mu\text{m}/\text{pix}$   
11:50 2023-06-15  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 2000 x

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above



646090 FDA\_083.jpg  
646090-9A  
Mica


11:46 2023-06-15  
TEM Mode: Diffraction  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


**Asbestos · Lead · Mold · Nano**



Chemistry from the Mica Particle Pictured Above



646090-9A, Elongated Talc Particle




646090 FDA\_094.jpg  
646090-9A  
Talc

Cal: 0.001905  $\mu\text{m}/\text{pix}$   
12:54 2023-06-15  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

600 nm  
HV=80kV  
Direct Mag: 5000 x

Asbestos · Lead · Mold · Nano

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_093.jpg  
646090-9A  
Talc

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.002387 µm/pix  
12:50 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-9A, Iron Particle




646090 FDA\_085.jpg  
646090-9A  
Iron particles

100 nm  
HV=80kV  
Direct Mag: 20000 x

Cal: 0.000477  $\mu\text{m}/\text{pix}$   
11:54 2023-06-15  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

*Diffraction Pattern from the Iron Particle Pictured Above*




646090 FDA\_086.jpg  
646090-9A  
Iron particles

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.000477  $\mu\text{m}/\text{pix}$   
11:54 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Iron Particle Pictured Above



646090-9A, Silica Sphere




646090 FDA\_092.jpg  
646090-9A  
Si sphere

Cal: 0.002387  $\mu\text{m}/\text{pix}$   
12:15 2023-06-15  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

600 nm  
HV=80kV  
Direct Mag: 4000 x

**Asbestos · Lead · Mold · Nano**

Chemistry from the Silica Sphere Pictured Above



646090-10A, 10B, 10C/Client Sample: 04032023-10

*PLM*  
All three aliquots of sample 04032023-10 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|            |                      |
|------------|----------------------|
| 646090-10A | No Asbestos Detected |
| 646090-10B | No Asbestos Detected |
| 646090-10C | No Asbestos Detected |


*TEM*  
(b) (6) analyzed aliquot 10A on June 15, 2023. (b) (6) analyzed aliquot 10B on June 19, 2023, and (b) (6) analyzed aliquot 10C on June 19, 2023. The primary particle observed was talc; talc ribbons/fibers, titanium particles, and iron particles were also observed along with mica particles, and particles containing magnesium, aluminum, silicon, and iron. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|            |                      |
|------------|----------------------|
| 646090-10A | No Asbestos Detected |
| 646090-10B | No Asbestos Detected |
| 646090-10C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**

646090-10A, Talc Particle




646090 FDA\_095.jpg  
606090-10a  
Talc

200 nm  
HV=80kV  
Direct Mag: 12000 x

Cal: 0.000817  $\mu\text{m}/\text{pix}$   
14:56 2023-06-15  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_096.jpg  
606090-10a  
Talc

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.000817  $\mu\text{m}/\text{pix}$   
14:59 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle pictured Above



646090-10A, Elongated Talc Particle



646090 FDA\_104.jpg  
606090-10a  
Talc

Cal: 0.000955  $\mu\text{m}/\text{pix}$   
15:40 2023-06-15  
TEM Mode: Imaging  
Microscopist(b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=80kV  
Direct Mag: 10000 x

Asbestos · Lead · Mold · Nano

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_103.jpg  
606090-10a  
Talc

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.000626 µm/pix  
15:36 2023-06-15  
TEM Mode: Diffraction  
Microscopist(s) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Chemistry from the Elongated Talc Particle pictured Above



Asbestos · Lead · Mold · Nano



646090-10A, Titanium Particles




646090 FDA\_097.jpg  
606090-10a  
Ti particles

100 nm  
HV=80kV  
Direct Mag: 20000 x

Cal: 0.000477  $\mu\text{m}/\text{pix}$   
15:02 2023-06-15  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Titanium Particles Pictured Above




646090 FDA\_098.jpg  
606090-10a  
Ti particles

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.000477  $\mu\text{m}/\text{pix}$   
15:03 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Titanium Particles pictured Above



646090-10A, Iron Particles



646090 FDA\_099.jpg  
606090-10a  
Fe particles

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
15:13 2023-06-15  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

400 nm  
HV=80kV  
Direct Mag: 8000 x

Asbestos · Lead · Mold · Nano

Diffraction Pattern from the Iron Particles Pictured Above




646090 FDA\_100.jpg  
606090-10a  
Fe particles

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.001209 μm/pix  
15:15 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Iron Particles pictured Above



Asbestos · Lead · Mold · Nano

646090-10B, Mica Particle



646090\_054.tif  
Mica

Cal: 0.001430  $\mu\text{m}/\text{pix}$   
10:41 2023-06-19  
TEM Mode: Imaging  
Microscopist<sup>(b)</sup> (S)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

400 nm  
HV=100kV  
Direct Mag: 7200 x

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above




646090\_055.tif

11:13 2023-06-19  
TEM Mode: Diffraction  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

**Asbestos · Lead · Mold · Nano**

Chemistry from the Mica Particle pictured Above



646090-10A, Particle Containing Magnesium, Aluminum, Silicon, and Iron




646090 FDA\_101.jpg  
606090-10a  
O,Mg,Al,Si,Fe particle

200 nm  
HV=80kV  
Direct Mag: 15000 x

Cal: 0.000626 µm/pix  
15:24 2023-06-15  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above




646090 FDA\_102.jpg  
606090-10a  
O,Mg,Al,Si,Fe particle

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.000626 µm/pix  
15:26 2023-06-15  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above



Asbestos · Lead · Mold · Nano

646090-11A, 11B, 11C/Client Sample: 04032023-11

*PLM*  
All three aliquots of sample 04032023-11 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.


|            |                      |
|------------|----------------------|
| 646090-11A | No Asbestos Detected |
| 646090-11B | No Asbestos Detected |
| 646090-11C | No Asbestos Detected |

*TEM*  
(b) (6) analyzed aliquot 11A on June 16, 2023. (b) (6) analyzed aliquot 11B on June 19, 2023, and (b) (6) analyzed aliquot 11C on June 19, 2023. The primary particle observed was talc; iron and aluminum particles were also observed along with talc ribbons/fibers, and particles containing magnesium, aluminum, silicon, and iron. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|            |                      |
|------------|----------------------|
| 646090-11A | No Asbestos Detected |
| 646090-11B | No Asbestos Detected |
| 646090-11C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.


646090-11A, Talc Particle



646090 FDA\_106.jpg  
646090-11A  
Talc Particle  
600 nm  
HV=80kV  
Direct Mag: 5000 x  
Cal: 0.001905 µm/pix  
10:13 2023-06-16  
TEM Mode: Imaging  
Microscopist<sup>®</sup>  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_105.jpg  
646090-11A  
Talc Particle

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m

10:12 2023-06-16  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Chemistry from the Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano



646090-11A, Iron Particles




646090 FDA\_110.jpg  
646090-11A  
Fe particles

400 nm  
HV=80kV  
Direct Mag: 8000 x

Cal: 0.001209  $\mu\text{m}/\text{pix}$   
10:19 2023-06-16  
TEM Mode: Imaging  
Microscopist: [B] [E]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Iron Particles Pictured Above




646090 FDA\_109.jpg  
646090-11A  
Fe particles

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.000817  $\mu\text{m}/\text{pix}$   
10:19 2023-06-16  
TEM Mode: Diffraction  
Microscopist: [B] [E]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Iron Particles Pictured Above



646090-11A, Aluminum Particle




646090 FDA\_112.jpg  
646090-11A  
Al Particle

Cal: 0.001612  $\mu\text{m}/\text{pix}$   
10:24 2023-06-16  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

500 nm  
HV=80kV  
Direct Mag: 6000 x

Asbestos • Lead • Mold • Nano

Diffraction Pattern from the Aluminum Particle Pictured Above




646090 FDA\_111.jpg  
646090-11A  
Al Particle

0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.001209 µm/pix  
10:23 2023-06-16  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Aluminum Particle Pictured Above



Asbestos · Lead · Mold · Nano

646090-11A, Particle Containing Aluminum and Titanium




646090 FDA\_108.jpg  
646090-11A  
Al,Ti particle

200 nm  
HV=80kV  
Direct Mag: 12000 x

Cal: 0.000817  $\mu\text{m}/\text{pix}$   
10:14 2023-06-16  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Particle Containing Aluminum and Titanium Pictured Above




646090 FDA\_107.jpg  
646090-11A  
Al,Ti particle

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.001905  $\mu\text{m}/\text{pix}$   
10:14 2023-06-16  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Particle Containing Aluminum and Titanium Pictured Above



646090-11A, Talc Ribbon




646090 FDA\_115.jpg  
646090-11A  
Talc Ribbon

Cal: 0.003183  $\mu\text{m}/\text{pix}$   
11:16 2023-06-16  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 3000 x


**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Talc Ribbon Pictured Above




646090 FDA\_114.jpg  
646090-11A  
Talc Ribbon  
0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.001209 µm/pix  
11:15 2023-06-16  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Talc Ribbon Pictured Above



Asbestos • Lead • Mold • Nano

646090-11A, Elongated Talc Particle




646090 FDA\_117.jpg  
646090-11A  
Talc Fiber

600 nm  
HV=80kV  
Direct Mag: 5000 x

Cal: 0.001905  $\mu\text{m}/\text{pix}$   
11:21 2023-06-16  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_116.jpg  
646090-11A  
Talc Fiber

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.003183  $\mu\text{m}/\text{pix}$   
11:20 2023-06-16  
TEM Mode: Diffraction  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Elongated Talc Particle Pictured Above



646090-11A, Particle Containing Magnesium, Aluminum, Silicon, and Iron




646090 FDA\_113.jpg  
646090-11A  
Mg,Al,Si,Fe particle  
Cal: 0.001209  $\mu\text{m}/\text{pix}$   
10:45 2023-06-16  
TEM Mode: Imaging  
Microscopist®  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

400 nm  
HV=80kV  
Direct Mag: 8000 x

Asbestos · Lead · Mold · Nano



Chemistry from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above



646090-12A, 12B, 12C/Client Sample: 04032023-12

*PLM*  
All three aliquots of sample 04032023-12 were analyzed by (b) (6) on June 9, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|            |                      |
|------------|----------------------|
| 646090-12A | No Asbestos Detected |
| 646090-12B | No Asbestos Detected |
| 646090-12C | No Asbestos Detected |


*TEM*  
(b) (6) analyzed aliquot 12A on June 16, 2023. (b) (6) analyzed aliquots 12B and 12C on June 19, 2023, and (b) (6) analyzed aliquot 11C on June 19, 2023. The primary particle observed was talc; calcium particles, silica spheres, and elongated titanium were also observed along with mica particles, talc ribbons/fibers, and particles containing magnesium, aluminum, silicon, and iron. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|            |                      |
|------------|----------------------|
| 646090-12A | No Asbestos Detected |
| 646090-12B | No Asbestos Detected |
| 646090-12C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**

646090-12A, Talc Particle




646090 FDA\_119.jpg  
646090-12a  
Talc

600 nm  
HV=80kV  
Direct Mag: 4000 x

Cal: 0.002387  $\mu\text{m}/\text{pix}$   
11:59 2023-06-16  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_118.jpg  
646090-12a  
Talc

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


11:55 2023-06-16  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle Pictured Above




646090-12A, Calcium Particles



646090 FDA\_120.jpg  
646090-12a  
Calcium particles  
100 nm  
HV=80kV  
Direct Mag: 20000 x  
Cal: 0.000477  $\mu\text{m}/\text{pix}$   
12:04 2023-06-16  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast


Asbestos · Lead · Mold · Nano

Diffraction Pattern from the Calcium Particles Pictured Above




646090 FDA\_121.jpg  
646090-12a  
Calcium particles  
0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.000477 μm/pix  
12:05 2023-06-16  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Calcium Particles Pictured Above



Asbestos · Lead · Mold · Nano

646090-12A, Silica Sphere




646090 FDA\_127.jpg  
646090-12a  
Si sphere

100 nm  
HV=80kV  
Direct Mag: 20000 x


Cal: 0.000477  $\mu\text{m}/\text{pix}$   
12:49 2023-06-16  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

*Chemistry from the Silica Sphere Pictured Above*



**Asbestos · Lead · Mold · Nano**

646090-12A, Elongated Titanium Particle




646090 FDA\_122.jpg  
646090-12a  
Ti fiber

200 nm  
HV=80kV  
Direct Mag: 15000 x

Cal: 0.000626  $\mu\text{m}/\text{pix}$   
12:17 2023-06-16  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Elongated Titanium Particle Pictured Above




646090 FDA\_123.jpg  
646090-12a  
Ti fiber

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


Cal: 0.000626  $\mu\text{m}/\text{pix}$   
12:19 2023-06-16  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Elongated Titanium Particle Pictured Above



646090-12B, Mica Particle




646090 FDA\_055.jpg  
646090-12B  
Mica particle

Cal: 0.003702  $\mu\text{m}/\text{pix}$   
18:00 2023-06-19  
TEM Mode: Imaging  
Microscopist(B) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 2900 x

Asbestos · Lead · Mold · Nano

Hexagonal Diffraction Pattern from the Mica Particle Pictured Above




646090 FDA\_054.jpg  
646090-12B  
Mica particle

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m

17:58 2023-06-19  
TEM Mode: Diffraction  
Microscopist: G  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Mica Particle Pictured Above



Asbestos · Lead · Mold · Nano



646090-12A, Talc Ribbon




646090 FDA\_126.jpg  
646090-12a  
Talc Ribbon

400 nm  
HV=80kV  
Direct Mag: 8000 x


Cal: 0.001209  $\mu\text{m}/\text{pix}$   
12:38 2023-06-16  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

*Chemistry from the Talc Ribbon Pictured Above*



**Asbestos · Lead · Mold · Nano**

646090-12A, Particle Containing Magnesium, Aluminum, Silicon, and Iron




646090 FDA\_124.jpg  
646090-12a  
O,Mg,Al,Si,Fe particle

2  $\mu\text{m}$   
HV=80kV  
Direct Mag: 1200 x

Cal: 0.007956  $\mu\text{m}/\text{pix}$   
12:31 2023-06-16  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above




646090 FDA\_125.jpg  
646090-12a  
O,Mg,Al,Si,Fe particle

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.007956  $\mu\text{m}/\text{pix}$   
12:33 2023-06-16  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Particle Containing Magnesium, Aluminum, Silicon, and Iron Pictured Above



646090-13A, 13B, 13C/Client Sample: 04032023-13

PLM

All three aliquots of sample 04032023-13 were analyzed by (b) (6) on June 20, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|            |                      |
|------------|----------------------|
| 646090-13A | No Asbestos Detected |
| 646090-13B | No Asbestos Detected |
| 646090-13C | No Asbestos Detected |

TEM


(b) (6) analyzed aliquot 13A on June 21, 2023. (b) (6) analyzed aliquot 13B on June 22, 2023, and (b) (6) analyzed aliquot 13C on June 22, 2023. The primary particle observed was talc; calcium particles were also observed along with talc ribbons/fibers and particles containing magnesium, aluminum, and silicon. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|            |                      |
|------------|----------------------|
| 646090-13A | No Asbestos Detected |
| 646090-13B | No Asbestos Detected |
| 646090-13C | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**

646090-13A, Talc Particle




646090 FDA\_129.jpg  
646090-13a  
Talc

1  $\mu\text{m}$   
HV=80kV  
Direct Mag: 3000 x

Cal: 0.003183  $\mu\text{m}/\text{pix}$   
09:54 2023-06-21  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_128.jpg  
646090-13a  
Talc

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m


09:50 2023-06-21  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle Pictured Above



646090-13A, Calcium Particles




646090 FDA\_130.jpg  
646090-13a  
Calcium particles  
Cal: 0.000955  $\mu\text{m}/\text{pix}$   
10:20 2023-06-21  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=80kV  
Direct Mag: 10000 x


**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Calcium Particles Pictured Above




646090 FDA\_131.jpg  
646090-13a  
Calcium particles  
0.2 Å<sup>-1</sup>  
HV=80kV  
Cam Len: 0.2000 m  
Cal: 0.000955 μm/pix  
10:21 2023-06-21  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Calcium Particles Pictured Above



Asbestos · Lead · Mold · Nano

646090-13A, Elongated Talc Particle



646090 FDA\_133.jpg  
646090-13a  
Talc Fiber

600 nm  
HV=80kV  
Direct Mag: 4000 x

Cal: 0.002387  $\mu\text{m}/\text{pix}$   
10:43 2023-06-21  
TEM Mode: Imaging  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_132.jpg  
646090-13a  
Talc Fiber

0.2  $\text{\AA}^{-1}$   
HV=80kV  
Cam Len: 0.2000 m

Cal: 0.000955  $\mu\text{m}/\text{pix}$   
10:40 2023-06-21  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS6, Exposure: 500 (ms) x 3 drift frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Elongated Talc Particle Pictured Above



646090-14, 15, 16/04032023-14.1, 14.2, 14.3

**PLM**  
Samples 04032023-14.1, 14.2, and 14.3 were analyzed by (b) (6) on June 20, 2023. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.

|           |                      |
|-----------|----------------------|
| 646090-14 | No Asbestos Detected |
| 646090-15 | No Asbestos Detected |
| 646090-16 | No Asbestos Detected |

**TEM**  
(b) (6) analyzed sample 14 on June 21, 2023. (b) (6) analyzed sample 15 on June 22, 2023, and (b) (6) analyzed sample 16 on June 22, 2023. The primary particles observed were titanium and particles containing chromium and iron; talc particles were also observed along with talc ribbons/fibers and particles containing magnesium, aluminum, and silicon. No asbestos or non-asbestos amphibole variants were observed during analysis. The results were calculated using the equations detailed in the *Calculations* section above.


|           |                      |
|-----------|----------------------|
| 646090-14 | No Asbestos Detected |
| 646090-15 | No Asbestos Detected |
| 646090-16 | No Asbestos Detected |

Below are pictures, diffraction patterns, and chemistry from some of the observed particles. The copper peaks in the chemistry spectra are from the TEM grid. The unidentified (and some identified) peaks in the chemistry spectra are zinc and carbon from the TEM specimen holder.

**Asbestos · Lead · Mold · Nano**



646090-14, Titanium Particles



646090 FDA\_057.jpg  
646090-14  
Ti particles

200 nm  
HV=100kV  
Direct Mag: 10000 x

Cal: 0.001030  $\mu\text{m}/\text{pix}$   
12:13 2023-06-21  
TEM Mode: Imaging  
Microscopist: [REDACTED]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Titanium Particles Pictured Above




646090 FDA\_056.jpg  
646090-14  
Ti particles

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m

12:12 2023-06-21  
TEM Mode: Diffraction  
Microscopist: [REDACTED]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Titanium Particles Pictured Above



646090-14, Elongated Particle Containing Chromium and Iron



646090 FDA\_061.jpg  
646090-14  
Cr,Fe structure

Cal: 0.000727  $\mu\text{m}/\text{pix}$   
12:25 2023-06-21  
TEM Mode: Imaging  
Microscopist: [REDACTED]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

200 nm  
HV=100kV  
Direct Mag: 14000 x

**Asbestos · Lead · Mold · Nano**

Diffraction Pattern from the Elongated Particle Containing Chromium and Iron Pictured Above




646090 FDA\_060.jpg  
646090-14  
Cr,Fe structure

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.002145 µm/pix  
12:24 2023-06-21  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Particle Containing Chromium and Iron Pictured Above



Asbestos · Lead · Mold · Nano

646090-14, Particle Containing Chromium and Iron



646090 FDA\_065.jpg  
646090-14  
Cr,Fe particle

600 nm  
HV=100kV  
Direct Mag: 4800 x

Cal: 0.002145  $\mu\text{m}/\text{pix}$   
12:54 2023-06-21  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Diffraction Pattern from the Particle Containing Chromium and Iron Pictured Above




646090 FDA\_064.jpg  
646090-14  
Cr,Fe particle

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.002860  $\mu\text{m}/\text{pix}$   
12:53 2023-06-21  
TEM Mode: Diffraction  
Microscopist: [signature]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Particle Containing Chromium and Iron Pictured Above



46090-14, Particle Containing Aluminum, Chromium, and Iron



646090 FDA\_063.jpg  
646090-14  
Al,Cr,Fe structure

Cal: 0.002860  $\mu\text{m}/\text{pix}$   
12:29 2023-06-21  
TEM Mode: Imaging  
Microscopist: [REDACTED]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

800 nm  
HV=100kV  
Direct Mag: 3600 x

**Asbestos • Lead • Mold • Nano**

Diffraction Pattern from the Particle Containing Aluminum, Chromium, and Iron Pictured Above




646090 FDA\_062.jpg  
646090-14  
Al,Cr,Fe structure

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.000727 µm/pix  
12:28 2023-06-21  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Particle Containing Aluminum, Chromium, and Iron Pictured Above



Asbestos · Lead · Mold · Nano

646090-14, Talc Particle




646090 FDA\_059.jpg  
646090-14  
Talc Particle

600 nm  
HV=100kV  
Direct Mag: 4800 x

Cal: 0.002145  $\mu\text{m}/\text{pix}$   
12:17 2023-06-21  
TEM Mode: Imaging  
Microscopist: [signature]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Hexagonal Diffraction Pattern from the Talc Particle Pictured Above




646090 FDA\_058.jpg  
646090-14  
Talc Particle

0.2  $\text{\AA}^{-1}$   
HV=100kV  
Cam Len: 0.2200 m


Cal: 0.001030  $\mu\text{m}/\text{pix}$   
12:16 2023-06-21  
TEM Mode: Diffraction  
Microscopist: [signature]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

**Asbestos · Lead · Mold · Nano**

Chemistry from the Talc Particle Pictured Above



646090-14, Elongated Talc Particle



646090 FDA\_067.jpg  
646090-14  
Talc fiber


Cal: 0.003702  $\mu\text{m}/\text{pix}$   
12:58 2023-06-21  
TEM Mode: Imaging  
Microscopist: [REDACTED]  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

1  $\mu\text{m}$   
HV=100kV  
Direct Mag: 2900 x

Asbestos • Lead • Mold • Nano



Hexagonal Diffraction Pattern from the Elongated Talc Particle Pictured Above




646090 FDA\_066.jpg  
646090-14  
Talc fiber

0.2 Å<sup>-1</sup>  
HV=100kV  
Cam Len: 0.2200 m

Cal: 0.002145 µm/pix  
12:56 2023-06-21  
TEM Mode: Diffraction  
Microscopist: (b) (6)  
Camera: NS5, Exposure: 840 (ms) x 5 std. frames, Gain: 1, Bin: 1  
Gamma: 1.00, No Sharpening, Normal Contrast

Chemistry from the Elongated Talc Particle Pictured Above



Asbestos · Lead · Mold · Nano

## QC Discussion

Microscope alignment and calibration for both the PLM and TEM scopes, and EDXA unit calibration were performed on each day of analysis as specified by method requirements and standard laboratory operating procedures. The analytical balance used for gravimetric reduction is verified weekly at three (3) tare levels using three NIST-traceable weights – 10.0-g, 0.1-g, 0.5-g – and on each day of operation using the 0.1-g and 0.5-g weights tared with an 8-mL glass vial. The muffle furnace is verified monthly at a temperature of 480°C. All equipment was functioning within normal operating parameters.

Matrix blank samples were prepared at rate of 10% or greater alongside the client samples with each series of samples that were put into the muffle furnace together. The matrix blank samples were prepared using Sigma-Aldrich Talc Powder 18654 (Cas No. 14807-96-6; EC No. 238-877-9, Lot 82330). Analysis of the matrix blank samples was only required if asbestos, or the non-asbestos versions of the regulated minerals, was found on the associated client samples unless otherwise noted. Matrix blank sample numbers NB23-285/286, NB23-312, NB23-332/333, NB23-337, NB23-342, and NB23-354 were not analyzed since no asbestos was observed on the associated client samples. Matrix blank sample number NB23-336 was analyzed by Ashley Rose on July 17, 2023. Although it was not required, (b) (6) analyzed matrix blank sample numbers NB23-311, NB23-341, and NB23-353 on July 17, 2023. No asbestos was observed on the matrix blank samples that were analyzed.

A talc reference control sample was randomly selected from our library of TEM grid preparations made from Sigma-Aldrich Talc Powder, <10 micron (Product No. 643604-500G; Batch No. 10830AJ) spiked with various levels of Chrysotile ranging from 0.4%-10%. One (1) reference control sample, sample number 646090-RB1, was analyzed with this set. It was analyzed by (b) (6) on July 10, 2023, and found to be within acceptable limits.

Filtration blank samples were prepared alongside the client samples with each use of the filtration apparatus. Analysis of these samples was only required on those blanks associated with a client sample on which asbestos, or the non-asbestos versions of the regulated minerals, was found unless otherwise noted. Filtration blank sample numbers 646090-DI01 through 646090-DI07 and 646090-DI09 through 646090-DI14 were not analyzed since no asbestos was observed on the associated client samples. Filtration blank sample number 646090-DI08 was analyzed by Michael Greenberg on July 10, 2023; no asbestos was observed on this sample.


TEM grid preparation (EB) blank samples were prepared with each batch of carbon coated filters. AMA policy is to analyze these blank samples whenever asbestos, or the non-asbestos versions of the regulated minerals, is detected on an associated client sample or when the laboratory blank identification number ends in a "0" or "5." EB Blank IDs 60355 and 60410 were analyzed by (b) (6) on July 10, 2023. Although it was not required, (b) (6) also analyzed EB Blank ID 60476 on July 10, 2023. No asbestos was detected on the TEM grid preparation blank samples that were analyzed.

Our laboratory information management system (LIMS) randomly selected sample 646090-14/04032023-14.1 (Tube Labeled 14.4) for additional duplicate QC analysis. Independent preparations were made for the PLM and TEM portions of analysis. The duplicate QC analysis was performed by (b) (6) on June 20, 2023, for PLM and by (b) (6) on July 18, 2023, for TEM. The QC results were consistent with the original findings.

Our laboratory information management system (LIMS) randomly selected samples 646090-1A/04032023-1 and 646090-12A/04032023-12 for additional replicate QC analysis. Independent preparations were made for the PLM and TEM portions of analysis. The PLM replicate QC analysis was performed by (b) (6) on June 20, 2023. (b) (6) performed TEM analysis on 646090-18RQC on July 17, 2023, and (b) (6) performed TEM analysis on 646090-19RQC on July 18, 2023. The QC results were consistent with the original findings.

**Asbestos · Lead · Mold · Nano**

I certify that all information contained in this report pertaining to laboratory events, procedures, and protocols is true to the best of my knowledge and accurately describes the handling of this project by AMA Analytical Services, Inc., and its personnel.



8/22/2023

Andreas Saldivar  
President

Date